



Service Manual

Compact Disc Audio Component System with Wireless Remote Control

DC DJ1 (EUROPE)



PRODUCT CODE No.
132 340 40

Specifications

Tuner Section

FM

Frequencies received	87.50 ~ 108.00 MHz
DIN 26dB Quiet Sensitivity (mono)	1 dB μ V/75 Ω
S/N ratio	70 dB (mono, 60 dB μ input)
Harmonic distortion	0.1 % (mono, 1 kHz)
Stereo separation	50 dB (1 kHz)
Image frequency interference ratio	90 dB

AM

Frequencies received	522 ~ 1611 kHz
Practical sensitivity (included antenna)	320 μ V/m
S/N ratio	55 dB
Image frequency interference ratio	40 dB
Selectivity	38 dB
IF interference ratio	70 dB

Amplifier Section

Output power (Front)	40 W (T.H.D 0.9 %)
Input sensitivity/impedance	
PHONO	2.5 mV/47 k Ω
DAT/VCR	200 mV/30 k Ω
AUX	200 mV/30 k Ω

DECK Section

Motor	DC motor (DECK 1 and DECK 2)
Head	Hi-B hard permalloy head (DECK 1 playback head, DECK 2 recording head) Ferrite head (DECK 2 erasing head)
Fast-forward/rewind time	Approx. 110 sec. (C-60 tape)
Tracks	4-track, 2-channel stereo
S/N ratio (playback)	50 dB
Frequency response	40 Hz ~ 16 kHz (metal tape)
Wow and flutter	0.08 % (WRMS)

CD Player Section

Frequency response	20 Hz ~ 20 kHz
Harmonic distortion	Less than 0.04 % (1 kHz)
S/N ratio	95 dB
Wow and flutter	Below measurable limits
Optical pickup	3-beam laser
Error correction	CIRC
Sampling frequency	44.1 kHz
D/A conversion	16-bit linear
Filter	Digital filter

General

Power requirements	AC: 220 V, 50 Hz
Power consumption	240 W
Dimensions (WxHxD)	360x455x320 mm
Weight (approx.)	12.9 kg


Specifications and design are subject to change without notice.

REFERENCE No. WM-570223



CONTENTS

Safety Certification	3
CD Player Disassembly Procedures	4
Removing the Disc Tray	4
Removing the Mechanism	4
Note for Assembling Disc Tray	4
CD Player Block Diagram	5
CD Player Adjustment Points	5
CD Player Adjustment Procedures	6
Before Checking or Adjusting CD Player	6
Free Run Frequency Adjustment	6
Setting of Initial Position of Volume	6
Focus Offset Adjustment	6
Tracking Offset Adjustment	6
Linear Motor Offset Adjustment	6
E/F Balance Adjustment	6
Kick Gain Adjustment	6
Adjustment of Focus/Tracking Gain	7
Focus Gain Adjustment	7
Tracking Gain Adjustment	7
Confirming Jitter and HF Level	8
Adjustment of Turntable Height	8
Diffraction Grid Adjustment	8
CD Player Mechanism Exploded View & Parts List	10
Block Diagram (Main Unit Section)	11
System Block Diagram (Function Section)	12
M-COM (LC6554H) System Block Diagram	13
Caution on RF Adjustment	14
System Clock Adjustment	14
FM Tuner Alignment	14
AM Tuner Alignment	15
Cassette Deck Electrical Adjustment	16
Before Adjustment	16
Measuring Instruments Required	16
Switch Positions	16
Normal Tape Speed Adjustment	16
High Speed Tape Speed Adjustment	16
Head Azimuth Adjustment	16
Playback Sensitivity Adjustment	17
FL Meter Sensitivity Adjustment	17
Recording Bias Level Adjustment (DECK2)	17
Cabinet Exploded View & Parts List	18
Cassette Deck Mechanism Exploded View & Parts List	21
P.C.Board Parts List	23
Wiring Diagram (CD Player Section)	51
Wiring Diagram (Power Main Section)	52
Wiring Diagram (Main Unit Section)	53
Schematic Diagram (Tuner Section)	55
Schematic Diagram (Deck/Function/Front Control Section)	57
Schematic Diagram (Deck/Function Section)	59
Schematic Diagram (CD Player Section)	61
Schematic Diagram (Main Power Section)	63
IC Block Diagram	64
IC & Transistor Lead Identification	73

SAFETY CERTIFICATION



Laser Diode Properties
 Material: Ga-Al-As
 Wavelength: 755 - 815 nm (25°C)
 Laser Output: Continuous Wave max. 0.5 mW




CAUTION - USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.
 THE UNIT SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT QUALIFIED SERVICE PERSONNEL.

BEFORE USE

CD PLAYER SECTION


Using a flat-blade screwdriver, turn the transport fixing screw on the bottom panel about 90° clockwise

- When transporting the unit again, such as when moving, remove the disc then turn the fixing screw about 90° counterclockwise.




REMOVING THE DISC TRAY

1. Push the **POWER** button to switch the power on and push the **OPEN/CLOSE** button to open the Disc Tray.
2. Push the **POWER** button to switch the power off while the Disc Tray is open.





1. Take out the four screws (1 ~ 4 in the diagram below) with which the mechanism is mounted in place and remove the mechanism.



1. Place the Disc Tray lever as illustrated and assemble the disc tray.

3. Now remove the Disc Tray from the cabinet while pressing the tab in the direction of the arrow in the diagram below.

[illegible]

CD PLAYER ADJUSTMENT PROCEDURES

BEFORE CHECKING OR ADJUSTING CD PLAYER

1. Procedures for all adjustments for the CD player from start to finish are described below.
2. If no problems are found after each item is checked when the pick-up is replaced, there is no need to adjust all items again.

FREE RUN FREQUENCY ADJUSTMENT

1. Connect the frequency counter to VCO test terminal (CN5) **PCK** test pin and to **GND**. (Use a 10:1 probe.)
2. Short the test point **TP4** (OSC ON) pin to **GND**.
3. Push the **POWER** button to switch the power on and push the **STOP** button.
4. Adjust the OSC coil T102 using a plastic screwdriver until the frequency counter indicator reads 4.3218MHz $\pm$ 10KHz.

SETTING OF INITIAL POSITION OF VOLUME

1. Set the variable resistors to the initial positions listed below:

P101 (FOCUS OFFSET)	Mechanical Center
P102 (E/F BALANCE)	Mechanical Center
P103 (TRACKING OFFSET)	Mechanical Center
P104 (TRACKING GAIN) ..	At the position of 45° in the clockwise from the Mechanical Center
P105 (KICK GAIN)	Mechanical Center
P106 (LINEAR MOTOR OFFSET) ..	Mechanical Center
P301 (FOCUS GAIN)	At the position of 45° in the clockwise from the Mechanical Center

FOCUS OFFSET ADJUSTMENT

1. Push the **POWER** button to switch the power on and push the **OPEN/CLOSE** button to open the Disc Tray and remove the disc.
2. Push the **OPEN/CLOSE** button to close the Disc Tray and push the **STOP** button.
3. Connect a DC Voltmeter to the test terminal (CN11) **F** (focus coil) pin and short the test terminal (CN5) **FCCS** pin to **GND**.
4. In this condition check that the DC Voltmeter indicator is in the range $-0.5V \pm 50mV$, and adjust P101 if it is not.

TRACKING OFFSET ADJUSTMENT

1. Push the **POWER** button to switch the power on and push the **STOP** button.
2. Connect a DC Voltmeter to the test terminal (CN11) **T** (tracking coil) pin and short the test point **TP11** (T-OF) pin to **GND**.
3. In this condition check that the DC Voltmeter indicator is in the range 100mV+50mV, and adjust P103 if it is not.

NOTE:


Perform this adjustment once again after adjusting the E/F BALANCE and TRACKING GAIN signals.

LINEAR MOTOR OFFSET ADJUSTMENT

1. Push the **POWER** button to switch the power on and push the **STOP** button.
2. Connect a DC Voltmeter to the test terminal (CN7) **LIN-
EAR MOTOR** pin.
3. In this condition check that the DC Voltmeter indicator is in the range $0V \pm 100mV$, and adjust P106 if it is not.

E/F BALANCE ADJUSTMENT

1. Place the test disc (Modern Wave II) on the Disc Tray, and play the fourth item on the disc. Short the test point **TP2** (TEST) pin to **GND**, and test terminal (CN15) **TOFF** pin to **GND** to turn tracking servo OFF.
2. Connect a DC Voltmeter and an oscilloscope via the low-pass filter like that shown in the illustration below to the test terminal (CN15) **TE** (tracking error) pin.



- Adjust P102 so that the DC Voltmeter reading is $0V \pm 50mV$ (oscilloscope waveform is symmetric to + and - about the zero level).

KICK GAIN ADJUSTMENT

1. Place the test disc (Modern Wave II) on the Disc Tray.
2. Set the oscilloscope to NORMAL TRIG., set the EXT. TRIG. pin to external trigger, and input the trigger from test point **TP10** (THLD) pin to the oscilloscope.
3. Next connect test point **TP14** (HF) pin to Channel 1 of the oscilloscope, and connect test terminal (CN15) **TE** pin to Channel 2.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc, and the push the PAUSE button. Now observe the waveforms for **HF** and **TE** with triggers applied from test point **TP10** (THLD) pin. At this point, adjust P105 so that a kick pulse waveform of about 1 to 1.3 tracks as shown in Fig. 1 below is obtained.





Fig. 1

CD PLAYER ADJUSTMENT PROCEDURES (Continued)

ADJUSTMENT OF FOCUS/TRACKING GAIN

The measurement circuit diagrammed below must be used in order to adjust focus gain and tracking gain correctly.

1. Use IC TA7256P or an equivalent product.
2. Short the interval between **IN** and **SG**, apply 1kHz, 1Vp-p from **SG**, and adjust variable resistor 2kΩ-B so that the **OUT** output is minimum.



FOCUS GAIN ADJUSTMENT

1. Apply P301 to the position of 45° in the clockwise from the center position, and place the test disc (Modern Wave II) on the Disc Tray.
2. Connect the measurement tool described in the last section to connector (CN12).
3. Connect the Pick-up Connector Plug to the measurement circuit.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc. Now apply a signal of 900Hz and 0.5Vp-p from the signal generator to the measurement circuit.
5. Set the oscilloscope to X-Y operation, and while observing the lissajous waveform adjust P301 to the point where the phase difference is 90° as shown in Fig. 2 below.

TRACKING GAIN ADJUSTMENT

1. Apply P104 to the position of 45° in the clockwise from the center position, and place the test disc (Modern Wave II) on the Disc Tray.
2. Connect the measurement tool described in the last section to the connector (CN12).
3. Connect the Pick-up Connector Plug to the measurement circuit.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc. Now apply a signal of 1600Hz and 0.5Vp-p from the signal generator to the measurement circuit.
5. Set the oscilloscope to X-Y operation, and while observing the lissajous waveform adjust P104 to the point where the phase difference is 90° as shown in Fig. 2 above.

NOTE:

If these two adjustments are performed, the TRACKING OFFSET must also be adjusted.




Fig. 2

CD PLAYER ADJUSTMENT PROCEDURES (Continued)

CONFIRMING JITTER AND HF LEVEL



If no jitter counter is available, this check does not have to be performed.

1. PLAY the fourth item on the test disc (Modern Wave II).
2. Connect an oscilloscope to the test point **TP14** (HF) pin, and check that its HF level is in the range 1.8Vp-p ~ 3.3Vp-p.
3. Connect a jitter counter to test terminal (CN5) **EFM** pin, and check that the 3T jitter value is less than 20ns. (Window width: 600ns ~ 850ns, Set Level: 2.5V)
4. Now PLAY the tenth item on the test disc and check that the jitter value is less than 20ns again.
5. If the results of the above procedure are not satisfactory, the Pick-up is damaged.

ADJUSTMENT OF TURNTABLE HEIGHT

This adjustment must be performed when the Spindle Motor is replaced.


1. The turntable should be mounted so that its upper surface is $13.75\text{mm} \pm 0.1\text{mm}$ above the surface of the chassis.




4. Push the POWER button to switch the power on and PLAY the First and Last Track No. on the disc.
5. If the DC Voltmeter reading is not in the ranges $0\text{V} \pm 0.2\text{V}$ for inner tracks and $0\text{V} \pm 0.35\text{V}$ for outer tracks, then the turntable height must be readjusted. Raise the turntable higher if the DC Voltmeter indicator is on the plus (+) side, and lower it if it is on the minus (-) side. (With this circuit 1V represents movement of approximately $0.55\text{mm} \sim 0.65\text{mm}$.)

DIFFRACTION GRID ADJUSTMENT

This set uses a three-beam laser pick-up system. Adjusting the diffraction grid means adjustment so that beams E and F are in position with respect to the main beam as shown in the diagram below on the bit streams.




The adjustment procedure involves arranging the three beams in a straight line along the same bit stream and then adjusting them to specified positions.




The adjustment steps are detailed below. These are very fine adjustments so great care should be exercised in this.

1. Push the POWER button to switch the power on and push the STOP button.
2. Short test point **TP2** (TEST) pin to the **GND**, and then short test terminal (CN15) **TOFF** pin to **GND** to turn the tracking servo OFF.
3. Place the test disc YEDS7 on the Disc Tray, and push the PLAY button.
4. In this state, connect the E-beam output of test terminal (CN15) to Channel 1 of the oscilloscope and F-beam output of test terminal (CN15) to Channel 2, and now observe the lissajous waveform on the oscilloscope.
5. When the disc begins to rotate a waveform will appear on the oscilloscope. While observing this waveform, move the Linear Motor in the direction of the arrow by hand to send the pick-up to the outer edge.



CD PLAYER ADJUSTMENT PROCEDURES (Continued)

6. When the pick-up approaches the outer edge, the waveform on the oscilloscope will suddenly disappear, and if it is now Pushd further outwards there will be points at which waveforms will appear again. These locations are the multiburst signal storage locations. If the disc rotates at high speed at this time, perform this step once again.



7. Set the oscilloscope to X-Y operation to bring up the waveforms. Insert the adjustment tool in the diffraction grating adjustment hole on the pick-up, and rotate the adjustment tool to right and left. The waveform should be almost a straight line with a phase difference of 0° as shown in Fig. 3 below. This indicates that the beams are arranged in one straight line. The waveform in Fig. 4 indicates that the beams are not arranged along the same stream.




Fig. 3



Fig. 4

NOTE:

It is important to turn the adjustment tool only a little at a time. If it is rotated too far, the beams will be pushed over into neighboring streams.



NOTE:

When inserting the adjustment pole into the adjustment hole, first place the disc mechanism with the decorate panel facing to your left, insert the small tip of the pole facing to your right and turn the pole clockwise. If the tip is inserted facing to your left and turned clockwise, the adjustment position of the diffraction grid moves in the reverse direction.

8. Next, when the waveform in Fig. 3 is obtained, turn the adjustment tool clockwise from that position at which the waveform in Fig. 3 appeared and adjust so that the waveform is a straight line with a phase difference of 180° . (See Fig. 5)




Fig. 5

9. Once the state indicated by the waveform in Fig. 5 is obtained, hold the STOP button down temporarily, and remove the connection between test point **TP2** (TEST) pin and the **GND** as well as that between test terminal (CN15) **TOFF** pin and **GND**.
10. Next, push the PLAY button, and set the oscilloscope in the DUAL MODE so that both E and F outputs can be seen. Set the DISPLAY TIME to $5\mu\text{s}$. Now, adjustment is complete if the waveforms shown below in Fig. 6 (Channel 1 trigger) are obtained.




Fig. 6


NOTE:

Diffraction grating adjustment is performed for a single pick-up, so if the following checks are performed adjustment is unnecessary.

- a. PLAY the fourth item on the test disc (Modern Wave II CA35-1045, Toshiba-EMI), turn the tracking servo OFF, and check that the waveform is linear with a phase difference of 180° .
- b. Next, apply tracking servo, and if the waveforms shown in Fig. 6 are obtained then adjustment is unnecessary.
- c. If this adjustment has been made, check other adjustment items.

CD PLAYER MECHANISM EXPLODED VIEW & PARTS LIST


Ref. No.	Part No.	Description	Q'ty
CD MECHANISM			
	620 125 8424	Wire Band	3
1	620 062 6200	Pick-up Assy 88 BS	1
2	620 183 4871	Holder Bobbin Assy	1
3	620 183 4888	Bobbin Assy	1
4	620 030 4290	Spindle Motor (Spindle) [M101]	1
5	620 183 4864	Holder Sensor Assy	1
6	620 051 4316	Screw 3X10	3
7	620 081 6069	Chassis Assy	1
8	620 121 6448	York Center	2
9	620 183 4895	York Side Assy	2
10	620 122 6324	Screw Washer	2
11	620 123 0116	Set Screw V-Cone 2X4	1
12	620 124 3321	Cushion	1
13	620 126 4104	Turntable	1
14	620 133 4104	Shaft Pick-up	2
15	620 015 3843	Leaf Switch (Open/Close) [SW101]	1
16	620 030 4108	Motor (Lid/Pick-up) [M102]	1
17	620 083 2878	Gear Rack Assy	1
18	620 188 4258	Table Load (Disc Tray)	1
19	620 184 9592	Table CD Assy	1
20	620 117 1280	Chassis (Load)	1
21	620 119 2223	Holder Disc	1
22	620 121 6493	York Magnet	1
23	620 122 9738	Screw, Blind Hd. Tapping-B, + M3.0X8	2
24	620 124 3437	Cushion Rubber	2
25	620 124 3444	Cushion Rubber	2
26	620 124 3628	Cushion Flap	1
27	620 184 9905	Pad Disc (Felt)	4
28	620 125 0145	Cushion Table Load	1
29	620 125 1005	Washer	1
30	620 127 9597	Gear Pulley	1
31	620 127 9603	Gear Pinion	1
32	620 128 6816	Belt	1
33	620 129 5993	Flap Disc Cramp	1
34	620 131 9835	Lever Table Load	1
35	620 133 4241	Shaft Damper	1
36	620 136 0769	Guide Table Load	2
37	620 138 0088	Spring Damper	1
38	620 139 2043	Spring Flap	1
39	620 139 4672	Spring Table CD	4
40	620 184 3026	Magnet Disc Clamp	1
41	620 192 6606	Pad Disc Hold	1
42	620 192 6613	Pad Damper	1
51	411 099 0701	SCR PAN PCS 1.7X3	2
52	411 020 7700	SCR S-TPG BRZ 3X6	1
53	411 020 8004	SCR S-TPG BRZ 3X8	1
54	411 021 0601	SCR S-TPG BIN 2X5	2
55	411 030 6403	SCR BIN 2X5	2
56	411 099 9407	SCR S-TPG BRZ 2.6X8	2
57	411 021 0304	SCR S-TPG BIN 2X4	1
58	411 021 0908	SCR S-TPG BIN 2X6	1
59	411 031 0905	SCR BIN 2.6X4	2
60	412 026 0108	SPECIAL SCREW	1
61	412 024 8700	SPECIAL SCREW	4
62	411 015 8903	RING E 2	1




NOTES:

- Parts order must contain Model Number, Part Number and Description.
- Ordering quantity of screws and resistors must be multiple of 10 pcs.


BLOCK DIAGRAM (Main Unit Section)



SYSTEM BLOCK DIAGRAM (Function Section)



SYSTEM BLOCK DIAGRAM (Deck Function Section)



CAUTION ON RF ADJUSTMENT

This model uses a microprocessor for memory preset control for the various bands. This function has been used to preset frequency points for the different bands to permit adjustment and make it possible to check the function of the microprocessor. To use this supplemental function, ground initialize point jumper wire JM826 for 1 second before beginning adjustment. The following table shows the initially preset frequencies.

Band	Memory											
	1	2	3	4	5	6	7	8	9	10	11	12
FM-1[MHz]	87.5	108.0	88.0	98.0	108.0	90.0	87.6	107.9	87.5	87.5	87.5	87.5
AM [kHz]	522	1611	603	1404	999	522	522	522	522	522	522	522

SYSTEM CLOCK ADJUSTMENT

Since this adjustment sets standard time for the total system, be sure to adjust before operation.

1. Connect the TP811 to the ground (The FL indicator goes out.)
2. Connect the Frequency Counter between the TP810 and ground.
3. Adjust the TC804 until the Frequency Counter reads 65.536kHz $\pm$ 0.1Hz.
(Avoid the minus " - " disparity as much as possible in case the clock lags behind.)
4. After the adjustment, Disconnect the TP811 from the ground and the original mode is returned.

FM TUNER ALIGNMENT

FM ALIGNMENT — FUNCTION switch to FM ST/MUTE position.
Note: It is almost unnecessary to adjust coil in Front End as perfectly adjusted

ITEM	GENERATOR	DIAL SETTING	INDICATOR	PROCEDURE
1. CENTER VOLTAGE& DETECTOR ADJUSTMENT (MINIMUM T.H.D.)	Connect FM RF signal generator through FM Dummy Antenna to FM Antenna terminals. Set generator output level to 60dB μ V at 98MHz $\pm$ 2kHz.	Set Preset STATION button to "4" position. Set to 98MHz. Set FM MODE switch to MONO.	Connect DC Voltmeter across TP804 and TP805.	Adjust FM DET 1st Coil (T806) until DC Voltmeter reads 0V $\pm$ 50mV.
			Connect Harmonic Distortion Analyzer to DAT OUT.	Adjust FM DET 2nd Coil (T807) for minimum gain and best linearity.
Note: Repeat Step 1 (FM DET 1st Coil T806) and 2 (FM DET 2nd Coil T807) until optimum alignment is reached.				
2. FM AUTO STOP ADJUSTMENT	Same as above. Adjust attenuator output level for 16dB μ V.	Same as above.	Front panel TUNED Indicator Display.	Set FM MODE Switch to ST/MUTE. Adjust P801 until the TUNED Indicator partly light up.
Note: Decrease the output level of ATT and confirm that the wave form disappears. Increase the output level of ATT again and confirm that the input level meets the specifications sufficiently when the wave form has appeared.				
3. FM STEREO SIGNAL SEPARATION CONTROL	Connect FM Stereo SG to FM Antenna terminals. Set generator output level to 60dB μ V at 98MHz stereo signal (1kHz-90%, Pilot-10%) from LEFT channel.	Same as above	Connect AC VTVM and Oscilloscope to (Right Channel) DAT OUT.	Adjust P803 for minimum output and checking the STEREO Indicator light up.
	Same as above for RIGHT channel.		Connect AC VTVM and Oscilloscope to (LEFT channel) DAT OUT	

Use a screwdriver with plastic grip for all adjustments.

AM TUNER ALIGNMENT

AM ALIGNMENT — FUNCTION switch to AM position.
Maintain generator output as low as possible for suitable indication.

Note: Perform this alignment after FM Tuner Alignment.

ITEM	GENERATOR	DIAL SETTING	INDICATOR	PROCEDURE
1. AM IF ALIGNMENT	Connect 450kHz Radio IF Genescope output to AM antenna terminal adjust output level to 70dB μ V.	Position of non-interference Minimum Frequency.	Connect Radio IF Genescope input to TP807 and ground lead to chassis.	Adjust AM IFT (T805) for maximum gain and best symmetry. Keep signal low enough for noise on response
2. AM RF FREQUENCY COVER ALIGNMENT (1611kHz)	Do not connect generator.	Set Preset STATION button to "2" position. Set to 1611kHz.	Connect DC Voltmeter to TP802 and ground lead to chassis.	Adjust AM OSC (T803) until DC Voltmeter reads 8.0V.
3. (522kHz)	Same as above.	Set Preset STATION button to "1" position. Set to 522kHz.	Same as above.	Check DC Voltmeter for Indication 1.0V ~ 1.5V.
Note: Repeat the adjustments in items 2 and 3. Then, confirm that each voltage becomes 1.3V to 8.0V at receiving frequency of 522kHz to 1611kHz. (See Table 1)				
4. AM RF TRACKING ALIGNMENT (603kHz)	Connect Standard Loop Antenna to output terminal of AM RF Signal Generator. Place Loop Antenna 60cm away from Loop antenna (Unit). Generator Setting to 603kHz or 1404kHz. Modulate with 400Hz (30 % modulation).	Set Preset STATION button to "3" position. Set to 603kHz.	Connect AC VTVM and Oscilloscope to DAT OUT.	Adjust AM ANT Coil (T801) for maximum gain output.
5. (1404kHz)		Change Preset STATION button to "4" position. Set to 1404kHz.	Same as above.	Adjust AM ANT Trimmer (TC801) for maximum gain output.
Note: Repeat the adjustments in Items 4 and 5. Then, confirm there is no tracking error.				
6. AM AUTO STOP SENSITIVITY ADJUSTMENT	Change generator setting to 999kHz and output level to 60dB μ V/m.	Set Preset STATION button to "5" position. Set to 999kHz.	Front Panel TUNED Indicator Display.	Adjust P802 until the TUNED Indicator partly light up.

Use a screwdriver with plastic grip for all adjustments.

**AM Frequency Cover Range
Tuning Voltage Value at TP802**

(Table 1)

	Minimum	Typical	Maximum
522kHz	1.0V	1.3V	1.5V
1611kHz	7.0V	8.0V	9.0V

CASSETTE DECK ELECTRICAL ADJUSTMENT

BEFORE ADJUSTMENT

If the tape surface which contacts the head, the capstan, and the pinch roller, etc., is stained, it will cause untangle running of the tape, wow and flutter, imperfect recording and erasing, deterioration of tonal quality, and the tape jam around the capstan, etc. Occasionally clean each part as follows;

1. Cut off power
2. Open the cassette lid.
3. Wipe the head, the capstan, and the pinch roller with a cotton swab. If they are excessively stained, clean them with the swab soaked in absolute alcohol or cleaning liquid on the market.

MEASURING INSTRUMENTS REQUIRED

- Dualtrace Oscilloscope
- AC VTVM (AC voltmeter with high impedance)
- Frequency Counter
- Signal Oscillator
- Test Tapes
 - ± 10kHz Test Tape (Example: TEAC MTT-114) for Azimuth Adjustment
 - ± 3kHz Test Tape (Example: TEAC MTT-111) for Normal Tape Speed Adjustment
 - ± 1.5kHz Test Tape (Example: A.BEX TCW-211) for Double Tape Speed Adjustment
 - ± 400Hz Test Tape (Example: TEAC MTT-150) for Playback Sensitivity Adjustment
- Test Tapes for Recording and Playback Operations
 - ± Normal Tape (Example: TDK AC 223)
 - ± CrO₂ Tape (Example: TDK AC 512)
 - ± Metal Tape (Example: TDK AC 712)

SWITCH POSITIONS

Unless especially indicated, set each switch as follows:

- Input Level Volume Center
- Surround Switch OFF
- Dolby NR Switch OFF
- Graphic Equalizer Controls FLAT

NORMAL TAPE SPEED ADJUSTMENT

1. Connect the frequency counter to the Dolby test point TP3 (Left Channel) or TP4 (Right Channel) on the DECK/FUNCTION P.C.Board.
2. Load Deck 1 with a test tape (Example: TEAC MTT-111) and set it in the playback mode.
3. Adjust the potentiometer inside the capstan drive motor, so that the output becomes 3000Hz $\pm$ 5Hz.
4. Perform the same adjustment for Deck 2.

HIGH SPEED TAPE SPEED ADJUSTMENT

1. Connect the frequency counter to the Dolby test point TP3 (Left Channel) or TP4 (Right Channel) on the DECK/FUNCTION P.C.Board.
2. Load Deck 1 with a test tape (Example: TEAC MTT-111) and set it in the playback mode.
3. Short circuit Test Point TP1 and GND on the DECK/FUNCTION P.C.Board.
(The set will be set to the high speed mode.)
4. Adjust VR305 on the DECK/FUNCTION P.C.Board so that the reading on the frequency counter is 6000Hz $\pm$ 10Hz.
5. Load Deck 2 with the same test tape.
6. Short circuit Test Point TP2 and GND on the DECK/FUNCTION P.C.Board.
7. Adjust VR306, so that the Deck 2 frequency should become as same as Deck 1.

HEAD AZIMUTH ADJUSTMENT


1. Connect the dualtrace oscilloscope and AC VTVM to the Dolby test point TP3 and TP4 (Left and Right channel) on the DECK/FUNCTION P.C.Board.

Then, set the dualtrace oscilloscope as follows:

- ± MODE CHOP (chopped)
- ± SOURCE INT (internal), CH1 or CH2
- ± SWEEP MODE AUTO (automatic)

NOTE:

1. Adjust the field on the oscilloscope with the VOLT. ADJ. and TIME ADJ.
2. Load Deck 1 with a test tape (Example: TEAC MTT-114) and set it in the forward playback mode.
3. Adjust the forward head azimuth adjustment screw, so that the wave forms become maximum on the oscilloscope and the Right channel wave form overlaps with the Left channel one.
4. Set the unit in the reverse playback mode and adjust the wave forms as described above instructions with the reverse head azimuth adjustment screw as well as the forward.



5. Repeat the above several time.
6. Adjust Deck 2 in the same way as for Deck 1.
7. After the adjustment, secure the adjusting screw with paint or glue.

CASSETTE DECK ELECTRICAL ADJUSTMENT (Continued)

PLAYBACK SENSITIVITY ADJUSTMENT

1. Connect the oscilloscope and AC VTVM to the Dolby test point TP3 and TP4 (Left and Right channel) on the DECK/FUNCTION P.C.Board.
2. Load Deck 1 with a test tape (Example: TEAC MTT-150) and set it in the playback mode.
3. Adjust potentiometer VR301 (Left Channel), so that the output level becomes 650mV $\pm$ 0.5dB.
4. Adjust potentiometer VR302 for the Right channel by following the same procedures as described for the Left channel.


FL METER SENSITIVITY ADJUSTMENT

1. After the playback sensitivity adjustment was made, playback the test tape (Example: TEAC MTT-150) on Deck 1.
2. Adjust potentiometer VR651 and VR652 (Left and Right channel) so that the Level meter indicates light up 0dB (Red point).

RECORDING BIAS LEVEL ADJUSTMENT (DECK2)


1. Connect the audio signal generator to the Left channel of the DAT/VTR input terminal, and the AC VTVM to the Dolby test point TP3 and TP4 (Left and Right channel) on the DECK/FUNCTION P.C.Board.
2. Load Deck 2 with a normal tape (Example: TDK AC223) and set it in the recording mode.
3. Function switch to the DAT/VTR position.
4. Set the Input Level ATT so that the output level becomes 30mV and feed the signals of 1kHz and 12.5kHz from the audio signal generator into the unit. Then, record the signals on the tape.
5. Playback the recorded signals and adjust potentiometer VR307 for the Left channel, so that the difference in output of the 1kHz and 12.5kHz signals become $\pm$ 1dB.
6. Adjust potentiometer VR308 for the Right channel by following the same procedures as described for the Left channel.

DECK/FUNCTION P.C.BOARD ALIGNMENT POINTS (BOTTOM VIEW)




CABINET EXPLODED VIEW & PARTS LIST

Ref. No.	Part No.	Description	Q'ty
PACKAGE			
	620 195 4654	Inner Carton	1
	620 062 0543	Serial No. Sheet	2
	620 189 2239	Pad Shoulder	1
	620 189 2857	Pad (Bottom)	1
	620 189 6732	Patching Sheet	1
	620 189 6749	Sheet Polyethylene	1
ACCESSORIES			
	411 123 3906	SCR TPG BIN 3X10	2
	620 195 7853	Remocon,DJ1MV	1
	620 196 3977	Instruction Manual,E,SWE	1
	620 197 6465	Instruction Manual	1
	620 195 8201	Label,Caution,Bottom	1
	620 195 8218	Label,Caution,Top	1
	620 197 1736	Label,POP,GE,Left	1
	620 197 1743	Label,POP,GE,Right	1
	620 197 1767	Label,POP,Deck 1	1
	620 198 6280	Label,R L	1
	620 038 1673	FM Antenna Assy	1
	620 057 8783	Bag Fan	1
	620 113 5312	Stand Loop Antenna	1
or	620 113 5305	Stand Antenna	1
	620 148 5561	Poly Cover 100 x 100	1
CABINET			
	620 054 1992	Label	1
	620 061 2340	Notes (Laser)	1
	620 061 2401	Notes (Laser)	1
	620 061 2418	Notes (Laser)	1
	620 062 0543	Serial No. Sheet	1
	620 189 4011	Tape Double Face	1
	620 125 8424	Wire Band	15
CN2	620 018 1501	Connector 3P Assy	1
CN6	620 018 1495	Connector 3P Assy	1
CN8	620 018 1990	Connector 2P Assy	1
CN9	620 018 1983	Connector 2P Assy	1
CN10	620 018 1976	Connector 2P Assy	1
CN22	620 018 2157	Connector 1P Assy	1
1	620 023 7550	Power Cord	1
2	620 196 6299	Power Trans,SEV	1
3	620 196 6305	Power Trans,SEV	1
4	620 047 3873	Leg	2
5	620 048 2608	Metal Mount (IC)	1
6	620 050 4317	Mount P.C.B.	4
7	620 050 4539	Mount P.C.B.	2
8	620 051 3708	Screw Braz. Hd. Tapp.-B. +M3X8	2
9	620 051 4149	Screw C-Tite 4X8 Z1	6
10	620 191 2746	Rivet 3.5	3
11	620 192 0949	Cover Shield	1
12	620 053 1993	Bushing (Antenna)	1
13	620 195 4661	Assy,Panel,Front	1
	620 197 9686	Panel,Front	1
	620 195 3152	Marking Plate,Indicator	1
	620 196 1522	Window	1
	620 195 1691	Knob,FM1,FM2	1
	620 195 1707	Knob,Mono,Stereo	1
	620 195 1714	Knob,Auto,Manual	1
	620 195 1721	Knob,AUX	1
	620 195 4784	Knob,DAT/VCR	1
	620 188 2551	Plate Dial	1
	620 188 2599	Panel Control	1
	620 047 4368	Leg	2
	620 050 3679	Filter	1
	620 189 3373	Knob Deck Assy	1
	620 188 4357	Window	1
	620 188 4418	Indicator Function	1
	620 188 4432	Indicator Remote	1
	620 188 3169	Clear Window	1
	620 188 3183	Filter	1
	620 188 4487	Filter	2
	620 188 4494	Filter Blue	1
	620 188 4500	Plate	1
	620 188 4517	Filter FL	1
	620 105 0936	Reflection ALM	2
	620 188 3435	Knob FF,REW	3
	620 188 3466	Knob CD 1	1
	620 188 3473	Knob CD 2	1
	620 188 3480	Knob CD 3	1



Ref. No.	Part No.	Description	Q'ty
	620 188 3497	Knob CD 4	1
	620 188 4753	Knob Timer	1
	620 188 4760	Knob Preset	1
	620 189 4356	Knob Mode Down	1
	620 188 4784	Knob UP	1
	620 188 4791	Knob AM	1
	620 188 4807	Knob Function	1
	620 189 4370	Knob Function Tape	1
	620 189 4394	Knob Function CD	1
	620 188 4814	Knob Phono	1
	620 188 4838	Knob Push	2
	620 188 4845	Knob Sleep	1
	620 188 4852	Knob Power	1
	620 116 3483	Adhesive Sheet	4
	620 116 4725	Adhesive Sheet	2
	620 189 4417	Adhesive Sheet	6
	620 189 4424	Adhesive Sheet	2
	620 189 4431	Adhesive Sheet	2
14	620 189 2444	Lid Cassette (Left) Assy	1
15	620 189 2451	Lid Cassette (Right) Assy	1
16	620 083 1789	Gear Eject Assy	2


CABINET EXPLODED VIEW & PARTS LIST (Continued)



Ref. No.	Part No.	Description	Q'ty
17	620 189 1041	Cover	1
18	620 195 4630	Panel,Rear	1
19	620 189 0525	Bottom Cover	1
20	620 188 3220	Cover Decorate Tray	1
21	620 188 4562	Knob Rotary	8
22	620 188 4579	Knob Volume	1
23	620 188 3428	Knob Rotary	1
24	620 188 3442	Knob Mode	2
25	620 188 3503	Knob Eject Right	1
26	620 188 3510	Knob Eject Left	1
27	620 195 5309	Chassis	1
28	620 196 6176	Shield,Cover	1
29	620 117 6797	Bracket P.C.B. Amplifier	1
30	620 117 6810	Bracket Right	1
31	620 117 6827	Bracket Left	1
32	620 117 6940	Bracket Support	1
33	620 189 1249	Bracket Volume	1
34	620 189 1256	Bracket Cover	1
35	620 189 1263	Fix Cover	1
36	620 189 1270	Bracket P.C.B. Tuner	1
37	620 188 3596	Metal Mount Mode	1
38	620 188 3602	Dolby Switch P.C.B. Assy	1
39	620 188 3619	Metal Mount Left	1
40	620 191 9790	Bracketmount	1

Ref. No.	Part No.	Description	Q'ty
41	620 189 7746	Plate Heat Sink	1
42	620 123 7658	Sheet	1
43	620 137 9990	Spring Lid Left	1
44	620 138 0002	Spring Lid Right	1
45	620 053 2136	Bushing (Power Cord)	1
46	620 122 2210	Holder Antenna	1
47	620 123 3186	Insulator	2
48	620 028 1966	Loop Antenna	1
51	620 197 9732	Assy,PCB Graphic EQ.	1
52	620 196 3236	Assy,PCB,Front Control	1
53	620 196 5483	Assy,PCB,CD Main	1
54	620 196 3212	Assy,PCB,Deck Function	1
55	620 196 5551	Assy,PCB,Main Power	1
56	620 197 4140	Assy,PCB,Tuner	1
57	620 196 5520	Assy,PCB,Main TRANS-1	1
58	620 196 5537	Assy,PCB,SUB Trans	1
59	620 196 5544	Assy,PCB,Beat Cancel	1
60	620 196 6275	Assy,PCB,Main TRANS-2	1
61	620 190 7223	Deck IND. P.C.B. Assy	1
62	620 190 7230	Volume P.C.B. Assy	1
63	620 190 7247	Dolby Switch P.C.B. Assy	1
64	620 190 7254	Headphone P.C.B. Assy	1
65	620 190 7261	T1 Switch P.C.B. Assy	1

CABINET EXPLODED VIEW & PARTS LIST (Continued)



Ref. No.	Part No.	Description	Q'ty
66	620 190 7278	T2 Switch P.C.B. Assy	1
67	620 190 7285	VR IND P.C.B. Assy	1
68	620 190 8008	PCB CD-Control Assy	1
69	620 191 1329	PL Power P.C.B. Assy	1
81	411 099 9506	SCR S-TPG BRZ 3X10	23
82	411 020 6208	SCR S-TPG BRZ 3X12	4
83	411 020 6406	SCR S-TPG BRZ 3X12	2
84	411 020 7007	SCR S-TPG BRZ 3X20	2
85	411 020 7700	SCR S-TPG BRZ 3X6	14
86	411 020 8004	SCR S-TPG BRZ 3X8	10
87	411 021 1202	SCR S-TPG BIN 2X8	7
88	411 021 2704	SCR S-TPG BIN 2.6X6	9
89	411 021 3107	SCR S-TPG BIN 2.6X8	30
90	411 021 6603	SCR S-TPG BIN 3X8	8
91	411 031 1001	SCR BIN 2.6X4	2
92	411 020 5904	SCR S-TPG BRZ 3X10	4
93	411 092 7806	WASHER Z 3.2X16X1	1

Ref. No.	Part No.	Description	Q'ty
----------	----------	-------------	------


NOTES:

- Parts order must contain Model Number, Part Number and Description.
- Ordering quantity of screws and resistors must be multiple of 10 pcs.

PRODUCT SAFETY NOTICE


Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol Δ in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified with Δ , use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.

CASSETTE DECK MECHANISM EXPLODED VIEW & PARTS LIST



Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
DECK 1 & DECK 2 SIMILAR PARTS							
	620 193 0986	Sheet	2	26	620 125 1630	Washer M1.5X3.5X0.4	4
	620 125 8110	Lug	2	27	620 125 1982	Washer, M2.1X4.0X0.25	2
1	620 016 9332	Leaf Switch	4	28	620 125 3450	Washer, M2.2X6.0X0.25	2
1	620 016 9332	Leaf Switch	3	29	620 125 3870	Washer, M2.6X6.0X0.25	2
2	620 016 9349	Leaf Switch	2	30	620 125 4280	Washer CUT, M3.4X6.0X0.4	2
3	620 029 3624	Plunger	2	31	620 125 4761	Washer, M2.4X4.5X0.25	2
4	620 030 3835	Motor	2	32	620 125 4846	Washer, M4.1X8.0X0.25	4
5	620 081 5857	Chassis Assy	2	33	620 126 6252	Reel Plate	4
6	620 082 2787	Plate Head Assy	2	34	620 126 6269	Fin Reel Supply	4
7	620 082 2848	Head Base Assy	2	35	620 126 6276	Fin Reel Take UP	2
8	620 082 7164	Flywheel FWD PB Assy	2	36	620 126 8492	Bush	4
9	620 082 7201	Flywheel REV Complete	2	37	620 127 8132	Gear Idler	2
10	620 083 0539	Arm Pinchroller Assy	4	38	620 127 8156	Gear Head	2
11	620 191 0483	Gear Motor Assy	2	39	620 127 8163	Gear Actuate	2
12	620 084 2471	Base Slide Assy	2	40	620 128 6533	Belt Drive	2
13	620 085 0902	Lever Assist B Assy	2	41	620 129 1292	Thrust Flywheel	4
14	620 119 1332	Bracket Switch	2	42	620 130 6019	Plate Azimuth	2
15	620 119 1561	Support Flywheel	2	43	620 130 6026	Plate Reverse	2
16	620 122 7277	Screw W/Washer + M2.0X6.0	6	44	620 137 9426	Spring Earth Reel	2
17	620 122 9356	Screw Washer + M2.6X1.5	4	45	620 130 6040	Rod Eject Base	2
18	620 123 0550	Screw + PMS M1.6X6.0	4	46	620 131 8982	Lever Lock Base	2
19	620 123 0901	Screw Azimuth	4	47	620 131 9002	Lever REV Select	2
20	620 123 1038	Screw C Switch M2X20	2	48	620 131 9019	Lever Play Start	2
21	620 123 5920	Sheet (Plunger)	2	49	620 132 4914	Arm Idler	2
22	620 123 9072	Cushion	2	50	620 136 9489	Spring Tension Arm	2
23	620 123 9942	Cushion Motor	4	51	620 136 9922	Spring Slide Base	2
24	620 124 5530	Cushion	4	52	620 137 4346	Spring Base Head	4
25	620 124 5950	Cushion	3	53	620 137 9051	Spring Arm Pinch Right	2
				54	620 137 9068	Spring Arm Pinch Left	2

CASSETTE DECK MECHANISM EXPLODED VIEW & PARTS LIST (Continued)



Ref. No.	Part No.	Description	Q'ty
55	620 137 9082	Spring Lever REV SEL	2
56	620 137 9099	Spring Lever Base	2
57	620 137 9358	Spring Earth FWD	2
58	620 137 9365	Spring Earth Reverse	2
59	620 138 9616	Spring Base	2
60	620 139 1077	Spring Lever Base	2
61	620 139 1121	Spring Lever Start	2
62	620 139 1220	Spring Gear Reverse	2
63	620 139 4139	Spring Azimuth	4
64	620 139 4207	Spring Reel FWD	2
65	620 139 4214	Spring Reel Reverse	2
66	620 011 1867	PCB Head	2
91	411 021 0809	SCR S-TPG BIN 2X6	2
92	411 021 1202	SCR S-TPG BIN 2X8	1
93	411 021 1806	SCR S-TPG BIN 2.6X10	11
94	411 044 7205	SCR PAN + SW 2X4	8
95	411 003 8809	SCR PAN + SW 2.6X6	4
96	411 045 5408	SCR PAN + SW 3X5	4
97	411 106 5606	SCR PAN + SW + W 2X20	2

Ref. No.	Part No.	Description	Q'ty
DECK 1 ONLY			
	620 017 6392	Connector 1P Assy [CA71]	1
	620 017 3667	Connector 1P Assy [CA72]	1
	620 018 0979	Connector 3P Assy [CA301]	1
	620 017 9706	Connector 8P Assy [CA304]	1
	620 191 6768	Connector 4P Assy [CA305]	1
71	620 191 7093	PB Rotary Head	1
72	620 124 5103	Cushion	2
73	620 130 6965	Rod Eject	1
DECK 2 ONLY			
	620 017 6392	Connector 1P Assy [CA73]	1
	620 017 3667	Connector 1P Assy [CA74]	1
	620 017 7085	Connector 6P Assy [CA302]	1
	620 191 6751	Connector 2P Assy [CA303]	1
	620 191 6775	Connector 8P Assy [CA306]	1
	620 191 6782	Connector 7P Assy [CA307]	1
81	620 191 7109	RP.E Rotary Head	1
82	620 192 4558	Cover Shield	1
83	620 124 7350	Cushion	2
84	620 130 6033	Rod Eject	1

NOTES:

- Parts order must contain Model Number, Part Number and Description.
- Ordering quantity of screws and resistors must be multiple of 10 pcs.

P.C.BOARD PARTS LIST

Ref. No.	Part No.	Description	Q'ty
ASSY,PCB GRAPHIC EQ.			
51	620 197 9732	Assy,PCB Graphic EQ.	1
	620 190 9593	VR 100K SWX2	7
CA311	620 017 6347	Connector 7P Assy	1
IC761	409 167 8803	IC AN7337	1
IC762	409 167 8803	IC AN7337	1
C761	403 164 4608	ELECT 100U M 25V	1
C762	403 164 4608	ELECT 100U M 25V	1
C765	403 050 8000	ELECT 3.3U M 50V	1
C766	403 050 8000	ELECT 3.3U M 50V	1
C767	403 056 8608	POLYESTER 1000P K 50V	1
C768	403 056 8608	POLYESTER 1000P K 50V	1
C769	403 050 8000	ELECT 3.3U M 50V	1
C770	403 050 8000	ELECT 3.3U M 50V	1
C771	403 067 8406	MT-COMPO 0.082U J 50V	1
C772	403 067 8406	MT-COMPO 0.082U J 50V	1
C773	403 050 1605	ELECT 2.2U M 50V	1
C774	403 050 1605	ELECT 2.2U M 50V	1
C775	403 067 7201	MT-COMPO 0.033U J 50V	1
C776	403 067 7201	MT-COMPO 0.033U J 50V	1
C777	403 049 2002	ELECT 1U M 50V	1
C778	403 049 2002	ELECT 1U M 50V	1
C779	403 058 2901	POLYESTER 0.015U J 50V	1
C780	403 058 2901	POLYESTER 0.015U J 50V	1
C781	403 048 5707	ELECT 0.33U M 50V	1
C782	403 048 5707	ELECT 0.33U M 50V	1
C783	403 062 5608	POLYESTER 5600P K 50V	1
C784	403 062 5608	POLYESTER 5600P K 50V	1
C785	403 067 6204	MT-COMPO 0.15U J 50V	1
C786	403 067 6204	MT-COMPO 0.15U J 50V	1
C787	403 059 4102	POLYESTER 2200P K 50V	1
C788	403 059 4102	POLYESTER 2200P K 50V	1
C789	403 067 7904	MT-COMPO 0.056U J 50V	1
C790	403 067 7904	MT-COMPO 0.056U J 50V	1
C791	403 075 4506	CERAMIC 820P K 50V	1
C792	403 075 4506	CERAMIC 820P K 50V	1
C793	403 059 6601	POLYESTER 0.022U K 50V	1
C794	403 059 6601	POLYESTER 0.022U K 50V	1
C795	403 072 8200	CERAMIC 330P K 50V	1
C796	403 072 8200	CERAMIC 330P K 50V	1
C797	403 057 0908	POLYESTER 0.01U K 50V	1
C798	403 057 0908	POLYESTER 0.01U K 50V	1
R647	401 025 7805	CARBON 2.2K JA 1/6W	1
R648	401 025 7805	CARBON 2.2K JA 1/6W	1
R649	401 025 7805	CARBON 2.2K JA 1/6W	1
R650	401 025 7805	CARBON 2.2K JA 1/6W	1
R761	401 026 0607	CARBON 270 JA 1/6W	1
R762	401 026 0607	CARBON 270 JA 1/6W	1
R765	401 025 7805	CARBON 2.2K JA 1/6W	1
R766	401 025 7805	CARBON 2.2K JA 1/6W	1
R767	401 025 7805	CARBON 2.2K JA 1/6W	1
R768	401 025 7805	CARBON 2.2K JA 1/6W	1
R769	401 024 7400	CARBON 10K JA 1/6W	1
R770	401 024 7400	CARBON 10K JA 1/6W	1
R771	401 027 2303	CARBON 560 JA 1/6W	1
R772	401 027 2303	CARBON 560 JA 1/6W	1
R773	401 025 7805	CARBON 2.2K JA 1/6W	1
R774	401 025 7805	CARBON 2.2K JA 1/6W	1
R775	401 026 1307	CARBON 27K JA 1/6W	1
R776	401 017 2801	CARBON 27K JA 1/4W	1
R777	401 026 1307	CARBON 27K JA 1/6W	1
R778	401 017 2801	CARBON 27K JA 1/4W	1
R779	401 025 7805	CARBON 2.2K JA 1/6W	1
R780	401 025 7805	CARBON 2.2K JA 1/6W	1
ASSY,PCB,FRONT CONTROL			
52	620 196 3236	Assy,PCB,Front Control	1
	620 185 3452	Digitron BG-601GK	1
	620 185 3469	Digitron BG-602GK	1
	620 026 9193	Ceramic Resonator	1
	620 030 8083	Lamp	4
	620 198 9410	Reflector	1
	620 062 1007	Tape Double Face 5	1
	620 188 4524	Reflector	1
	620 121 2549	Spacer Lamp	1
	620 188 4883	Holder LED	1
	620 189 1324	Cushion FL	2
	620 189 5889	Cushion FL	2
CA308	620 191 6799	Connector 8P Assy	1
Ref. No.	Part No.	Description	Q'ty
CA309	620 191 6805	Connector 3P Assy	1
CA313	620 191 6843	Connector 3P Assy	1
CA314	620 191 6850	Connector 7P Assy	1
CA501	620 191 6829	Connector 6P Assy	1
CA503	620 191 6935	Connector 3P Assy	1
CA802	620 191 6966	Connector 12P Assy	1
CA952	620 191 6911	Connector 10P Assy	1
CA954	620 191 6928	Connector 6P Assy	1
RA651	620 191 0292	Resistor 13X100K	1
RA652	620 191 0292	Resistor 13X100K	1
RA653	620 004 5254	Resistor 100K-8 J	1
RA654	620 004 5254	Resistor 100K-8 J	1
RA655	620 004 5254	Resistor 100K-8 J	1
RA656	620 004 5254	Resistor 100K-8 J	1
RA657	620 004 5209	Resistor 4X10K J	1
S651	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S652	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S653	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S654	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S655	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S656	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S657	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S658	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S659	620 014 8337	Keyboard Switch	1
S801	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S802	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S803	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S804	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S805	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S806	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S807	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S808	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S809	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S810	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S811	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S812	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S813	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S814	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S815	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S816	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S817	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S818	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S819	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S820	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S821	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S822	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S823	620 016 7819	Tact Switch	160G
or	620 195 9628	Switch,Tact	1
S824	620 016 7819	Tact Switch	160G

P.C.BOARD PARTS LIST (Continued)

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
or	620 195 9628	Switch,Tact	1	C652	403 069 1504	CERAMIC 1000P K 50V	1
S825	620 016 7819	Tact Switch 160G	1	C653	403 051 2304	ELECT 4.7U M 50V	1
or	620 195 9628	Switch,Tact	1	C654	403 067 5603	MT-COMPO 0.1U J 50V	1
S826	620 016 7819	Tact Switch 160G	1	C655	403 044 8504	ELECT 10U M 25V	1
or	620 195 9628	Switch,Tact	1	C656	403 045 0606	ELECT 100U M 25V	1
VR651	620 190 9654	Potentiometer 1KB	1	C657	403 045 0606	ELECT 100U M 25V	1
VR652	620 190 9654	Potentiometer 1KB	1	C658	403 001 2309	CERAMIC 0.01U N 16V	1
VR653	620 190 9661	VR 50KW	1	C659	403 069 5205	CERAMIC 0.01U K 50V	1
IC651	409 170 4205	IC LC8554H-3863	1	C660	403 002 2902	CERAMIC 0.01U M 25V	1
IC652	409 121 1505	IC L78LR05E-MA	1	C661	403 069 5205	CERAMIC 0.01U K 50V	1
IC653	409 118 0603	IC LC7566	1	C663	403 003 3601	CERAMIC 0.022U N 25V	1
IC654	409 118 0603	IC LC7566	1	C664	403 003 3601	CERAMIC 0.022U N 25V	1
IC655	409 143 7004	IC BA14741	1	C665	403 003 3601	CERAMIC 0.022U N 25V	1
IC656	409 143 7004	IC BA14741	1	C666	403 003 3601	CERAMIC 0.022U N 25V	1
IC657	409 143 7004	IC BA14741	1	C667	403 003 3601	CERAMIC 0.022U N 25V	1
IC658	409 143 7004	IC BA14741	1	C668	403 003 3601	CERAMIC 0.022U N 25V	1
Q651	405 018 2600	TR 2SC3400	1	C669	403 003 3601	CERAMIC 0.022U N 25V	1
Q652	405 018 2600	TR 2SC3400	1	C670	403 003 3601	CERAMIC 0.022U N 25V	1
Q653	405 018 2600	TR 2SC3400	1	C671	403 005 1605	CERAMIC 4700P M 50V	1
Q654	405 018 2600	TR 2SC3400	1	C672	403 005 1605	CERAMIC 4700P M 50V	1
Q655	405 018 2600	TR 2SC3400	1	C673	403 005 1605	CERAMIC 4700P M 50V	1
Q656	405 018 2600	TR 2SC3400	1	C674	403 005 1605	CERAMIC 4700P M 50V	1
Q657	405 024 9907	TR 2SD734-F	1	C675	403 004 9602	CERAMIC 2200P M 50V	1
or	405 025 0200	TR 2SD734-G	1	C676	403 004 9602	CERAMIC 2200P M 50V	1
Q658	405 024 9907	TR 2SD734-F	1	C677	403 004 9602	CERAMIC 2200P M 50V	1
or	405 025 0200	TR 2SD734-G	1	C678	403 004 9602	CERAMIC 2200P M 50V	1
Q659	405 024 9907	TR 2SD734-F	1	C679	403 004 2207	CERAMIC 5600P M 25V	1
or	405 025 0200	TR 2SD734-G	1	C680	403 004 2207	CERAMIC 5600P M 25V	1
Q660	405 024 9907	TR 2SD734-F	1	C681	403 004 2207	CERAMIC 5600P M 25V	1
or	405 025 0200	TR 2SD734-G	1	C682	403 004 2207	CERAMIC 5600P M 25V	1
Q661	405 019 2807	TR 2SC536-F-SPA-AC	1	C683	403 004 9602	CERAMIC 2200P M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C684	403 004 9602	CERAMIC 2200P M 50V	1
Q662	405 019 2807	TR 2SC536-F-SPA-AC	1	C685	403 004 9602	CERAMIC 2200P M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C686	403 004 9602	CERAMIC 2200P M 50V	1
Q663	405 019 2807	TR 2SC536-F-SPA-AC	1	C687	403 004 9602	CERAMIC 2200P M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C688	403 004 9602	CERAMIC 2200P M 50V	1
Q664	405 019 2807	TR 2SC536-F-SPA-AC	1	C689	403 004 9602	CERAMIC 2200P M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C690	403 004 9602	CERAMIC 2200P M 50V	1
Q667	405 004 4601	TR 2SA808-F-SPA-AC	1	C691	403 004 8803	CERAMIC 1500P N 50V	1
Q667	405 004 5103	TR 2SA808-G-SPA-AC	1	C692	403 004 8803	CERAMIC 1500P N 50V	1
Q668	405 018 2600	TR 2SC3400	1	C693	403 042 0708	ELECT 10U M 16V	1
Q669	405 018 2600	TR 2SC3400	1	C694	403 042 0708	ELECT 10U M 16V	1
Q670	405 019 2807	TR 2SC536-F-SPA-AC	1	C695	403 042 0708	ELECT 10U M 16V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C696	403 042 0708	ELECT 10U M 16V	1
	407 088 6601	SENSOR BX-1407	1	C697	403 049 1906	ELECT 1U M 50V	1
D651	407 008 0405	DIODE GMB01-BT	1	C698	403 049 1906	ELECT 1U M 50V	1
D652	407 008 0405	DIODE GMB01-BT	1	C699	403 049 1906	ELECT 1U M 50V	1
D653	407 008 0405	DIODE GMB01-BT	1	C700	403 049 1906	ELECT 1U M 50V	1
D654	407 008 0405	DIODE GMB01-BT	1	C701	403 049 1906	ELECT 1U M 50V	1
D655	407 008 0405	DIODE GMB01-BT	1	C702	403 049 1906	ELECT 1U M 50V	1
D656	407 008 0405	DIODE GMB01-BT	1	C703	403 049 1906	ELECT 1U M 50V	1
D657	407 008 0405	DIODE GMB01-BT	1	C704	403 049 1906	ELECT 1U M 50V	1
D658	407 008 0405	DIODE GMB01-BT	1	C705	403 049 1906	ELECT 1U M 50V	1
D659	407 008 7305	DIODE MA700A-TA	1	C706	403 049 1906	ELECT 1U M 50V	1
D660	407 008 7305	DIODE MA700A-TA	1	C707	403 049 1906	ELECT 1U M 50V	1
D661	407 008 7305	DIODE MA700A-TA	1	C708	403 049 1906	ELECT 1U M 50V	1
D662	407 008 7305	DIODE MA700A-TA	1	C709	403 049 1906	ELECT 1U M 50V	1
D663	407 008 7305	DIODE MA700A-TA	1	C710	403 049 1906	ELECT 1U M 50V	1
D664	407 008 7305	DIODE MA700A-TA	1	C711	403 049 1906	ELECT 1U M 50V	1
D665	407 008 7305	DIODE MA700A-TA	1	C712	403 049 1906	ELECT 1U M 50V	1
D666	407 008 7305	DIODE MA700A-TA	1	C713	403 049 1906	ELECT 1U M 50V	1
D667	407 008 7305	DIODE MA700A-TA	1	C714	403 049 1906	ELECT 1U M 50V	1
D668	407 008 7305	DIODE MA700A-TA	1	C717	403 038 7209	ELECT 220U M 6.3V	1
D669	407 008 7305	DIODE MA700A-TA	1	C718	403 038 7209	ELECT 220U M 6.3V	1
D670	407 008 7305	DIODE MA700A-TA	1	C719	403 038 2709	ELECT 100U M 6.3V	1
D671	407 008 7305	DIODE MA700A-TA	1	C720	403 074 2701	CERAMIC 0.047U Z 50V	1
D672	407 008 7305	DIODE MA700A-TA	1	C721	403 074 2701	CERAMIC 0.047U Z 50V	1
D673	407 008 7305	DIODE MA700A-TA	1	C722	403 074 2701	CERAMIC 0.047U Z 50V	1
D674	407 008 7305	DIODE MA700A-TA	1	C723	403 074 2701	CERAMIC 0.047U Z 50V	1
D675	407 112 7307	LED SLB-55DU3F	1	C724	403 074 2701	CERAMIC 0.047U Z 50V	1
D676	407 112 7505	LED SLP-671B-01	1	C725	403 049 2002	ELECT 1U M 50V	1
D677	407 112 7505	LED SLP-671B-01	1	R651	401 026 3905	CARBON 330 JA 1/6W	1
D678	407 112 7505	LED SLP-671B-01	1	R652	401 024 6700	CARBON 100 JA 1/6W	1
D679	407 112 7505	LED SLP-671B-01	1	R653	401 024 6700	CARBON 100 JA 1/6W	1
D680	407 005 3805	DIODE DS442-BT	1	R654	401 024 6700	CARBON 100 JA 1/6W	1
D681	407 005 3805	DIODE DS442-BT	1	R655	401 024 6700	CARBON 100 JA 1/6W	1
D682	407 050 7308	ZENER DIODE GZA8.2Y-BT	1	R656	401 024 9305	CARBON 1.2K JA 1/6W	1
D683	407 050 7308	ZENER DIODE GZA8.2Y-BT	1	R657	402 015 6402	FUSIBLE RES 2.2 J- 1/4W	1
C651	403 001 2309	CERAMIC 0.01U N 16V	1	R658	402 015 6402	FUSIBLE RES 2.2 J- 1/4W	1

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
R659	402 015 6402	FUSIBLE RES 2.2 J- 1/4W	1	R739	401 025 1902	CARBON 15K JA 1/6W	1
R660	402 015 6402	FUSIBLE RES 2.2 J- 1/4W	1	R740	401 025 1902	CARBON 15K JA 1/6W	1
R661	401 026 9907	CARBON 4.7K JA 1/6W	1	R741	401 025 1902	CARBON 15K JA 1/6W	1
R662	401 024 7400	CARBON 10K JA 1/6W	1	R742	401 025 1902	CARBON 15K JA 1/6W	1
R663	401 026 9907	CARBON 4.7K JA 1/6W	1	R743	401 024 7400	CARBON 10K JA 1/6W	1
R664	401 024 7400	CARBON 10K JA 1/6W	1	R744	401 024 7400	CARBON 10K JA 1/6W	1
R665	401 026 9907	CARBON 4.7K JA 1/6W	1	R745	401 024 7707	CARBON 100K JA 1/6W	1
R666	401 024 7400	CARBON 10K JA 1/6W	1	R746	401 012 8105	CARBON 100K JA 1/4W	1
R667	401 026 9907	CARBON 4.7K JA 1/6W	1	R747	401 024 7004	CARBON 1K JA 1/6W	1
R668	401 024 7400	CARBON 10K JA 1/6W	1	R748	401 024 7004	CARBON 1K JA 1/6W	1
R669	401 026 9600	CARBON 470 JA 1/6W	1	R749	401 024 7707	CARBON 100K JA 1/6W	1
R670	401 024 7707	CARBON 100K JA 1/6W	1	R750	401 024 7707	CARBON 100K JA 1/6W	1
R671	401 027 9005	CARBON 82K JA 1/6W	1	R751	401 024 7707	CARBON 100K JA 1/6W	1
R672	401 024 7400	CARBON 10K JA 1/6W	1	R752	401 024 7707	CARBON 100K JA 1/6W	1
R673	401 024 7707	CARBON 100K JA 1/6W	1	R753	401 026 4308	CARBON 3.3K JA 1/6W	1
R674	401 012 7009	CARBON 10K JA 1/4W	1	R754	401 026 4308	CARBON 3.3K JA 1/6W	1
R675	401 024 7400	CARBON 10K JA 1/6W	1	R755	401 024 7707	CARBON 100K JA 1/6W	1
R676	401 020 0801	CARBON 470 JA 1/4W	1	R756	401 012 8105	CARBON 100K JA 1/4W	1
R677	401 020 0801	CARBON 470 JA 1/4W	1	R757	401 024 7400	CARBON 10K JA 1/6W	1
R679	401 025 3302	CARBON 16K JA 1/6W	1	R758	401 024 7400	CARBON 10K JA 1/6W	1
R680	401 025 3302	CARBON 16K JA 1/6W	1	R759	401 024 7400	CARBON 10K JA 1/6W	1
R681	401 025 2305	CARBON 150K JA 1/6W	1	R760	401 024 7400	CARBON 10K JA 1/6W	1
R682	401 025 2305	CARBON 150K JA 1/6W	1	R761	401 012 7009	CARBON 10K JA 1/4W	1
R683	401 028 0526	CARBON 910K JA 1/6W	1				
R684	401 028 0526	CARBON 910K JA 1/6W	1				
R685	401 027 4307	CARBON 6.2K JA 1/6W	1				
R686	401 027 4307	CARBON 6.2K JA 1/6W	1				
R687	401 027 4604	CARBON 62K JA 1/6W	1				
R688	401 027 4604	CARBON 62K JA 1/6W	1				
R689	401 026 6302	CARBON 360K JA 1/6W	1				
R690	401 026 6302	CARBON 360K JA 1/6W	1				
R691	401 024 9701	CARBON 12K JA 1/6W	1				
R692	401 024 9701	CARBON 12K JA 1/6W	1				
R693	401 024 8704	CARBON 110K JA 1/6W	1				
R694	401 024 8704	CARBON 110K JA 1/6W	1				
R695	401 027 6103	CARBON 680K JA 1/6W	1				
R696	401 027 6103	CARBON 680K JA 1/6W	1				
R697	401 024 7400	CARBON 10K JA 1/6W	1				
R698	401 024 7400	CARBON 10K JA 1/6W	1				
R699	401 028 0308	CARBON 91K JA 1/6W	1				
R700	401 028 0308	CARBON 91K JA 1/6W	1				
R701	401 027 3201	CARBON 560K JA 1/6W	1				
R702	401 027 3201	CARBON 560K JA 1/6W	1				
R703	401 025 3005	CARBON 1.6K JA 1/6W	1				
R704	401 025 3005	CARBON 1.6K JA 1/6W	1				
R705	401 025 1902	CARBON 15K JA 1/6W	1				
R706	401 025 1902	CARBON 15K JA 1/6W	1				
R707	401 028 0308	CARBON 91K JA 1/6W	1				
R708	401 028 0308	CARBON 91K JA 1/6W	1				
R709	401 025 3005	CARBON 1.6K JA 1/6W	1				
R710	401 025 3005	CARBON 1.6K JA 1/6W	1				
R711	401 025 1902	CARBON 15K JA 1/6W	1				
R712	401 025 1902	CARBON 15K JA 1/6W	1				
R713	401 028 0308	CARBON 91K JA 1/6W	1				
R714	401 028 0308	CARBON 91K JA 1/6W	1				
R715	401 027 4000	CARBON 620 JA 1/6W	1				
R716	401 027 4000	CARBON 620 JA 1/6W	1				
R717	401 027 4307	CARBON 6.2K JA 1/6W	1				
R718	401 027 4307	CARBON 6.2K JA 1/6W	1				
R719	401 026 6104	CARBON 36K JA 1/6W	1				
R720	401 026 6104	CARBON 36K JA 1/6W	1				
R721	401 025 4606	CARBON 18K JA 1/6W	1				
R722	401 025 4606	CARBON 18K JA 1/6W	1				
R723	401 024 7707	CARBON 100K JA 1/6W	1				
R724	401 024 7707	CARBON 100K JA 1/6W	1				
R725	401 024 7707	CARBON 100K JA 1/6W	1				
R726	401 024 7707	CARBON 100K JA 1/6W	1				
R727	401 025 1902	CARBON 15K JA 1/6W	1				
R728	401 025 1902	CARBON 15K JA 1/6W	1				
R729	401 025 1902	CARBON 15K JA 1/6W	1				
R730	401 025 1902	CARBON 15K JA 1/6W	1				
R731	401 025 1902	CARBON 15K JA 1/6W	1				
R732	401 025 1902	CARBON 15K JA 1/6W	1				
R733	401 025 1902	CARBON 15K JA 1/6W	1				
R734	401 025 1902	CARBON 15K JA 1/6W	1				
R735	401 025 1902	CARBON 15K JA 1/6W	1				
R736	401 025 1902	CARBON 15K JA 1/6W	1				
R737	401 025 1902	CARBON 15K JA 1/6W	1				
R738	401 025 1902	CARBON 15K JA 1/6W	1				

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
IC114	409 164 3801	IC LC6538D-3843	1	C106	403 014 6202	CERAMIC 18P K 50V	1
IC115	409 031 8106	OK MC7805CT	1	C107	403 031 0306	CERAMIC 68P K 50V	1
or	409 040 0603	IC NJM7805A	1	C108	403 015 0407	CERAMIC 180P K 50V	1
IC116	409 031 8205	IC MC79L05ACP	1	C109	403 048 7602	ELECT 0.47U M 50V	1
or	409 050 1706	IC TA79L005P	1	C110	403 031 0306	CERAMIC 68P K 50V	1
IC117	409 183 7705	IC NJM79L07A	1	C111	403 057 0908	POLYESTER 0.01U K 50V	1
or	409 073 1301	IC AN79L07	1	C112	403 018 8509	CERAMIC 220P K 50V	1
IC118	409 183 7606	IC NJM78L07A	1	C113	403 061 4404	POLYESTER 0.039U K 50V	1
or	409 142 3106	IC TA78L007P	1	C114	403 087 2507	STYRENE 1000P J 50V	1
Q101	405 036 7403	TR 25C2999-F-SPA	1	C115	403 057 0908	POLYESTER 0.01U K 50V	1
or	405 016 5900	TR 25C2999-E-SPA	1	C116	403 067 7706	MT-COMPO 0.047U J 50V	1
Q102	405 019 2708	TR 25C536-F-NP-AA	1	C117	403 057 0908	POLYESTER 0.01U K 50V	1
or	405 019 3804	TR 25C536-G-NP-AA	1	C118	403 060 6607	POLYESTER 3300P K 50V	1
Q103	405 019 2708	TR 25C536-F-NP-AA	1	C119	403 067 6204	MT-COMPO 0.15U J 50V	1
or	405 019 3804	TR 25C536-G-NP-AA	1	C120	403 067 6709	MT-COMPO 0.22U J 50V	1
Q104	405 021 0600	TR 2SD1012-G-SPA-AC	1	C121	403 067 7300	MT-COMPO 0.33U J 50V	1
or	405 021 0204	TR 2SD1012-F-SPA-AC	1	C122	403 149 7105	POLYPRO 680P J 100V	1
Q105	405 021 0600	TR 2SD1012-G-SPA-AC	1	C123	403 060 8700	POLYESTER 0.033U K 50V	1
or	405 021 0204	TR 2SD1012-F-SPA-AC	1	C124	403 067 5603	MT-COMPO 0.1U J 50V	1
Q106	405 021 0600	TR 2SD1012-G-SPA-AC	1	C125	403 042 0302	ELECT 10U M 16V	1
or	405 021 0204	TR 2SD1012-F-SPA-AC	1	C126	403 074 2701	CERAMIC 0.047U Z 50V	1
Q107	405 021 0600	TR 2SD1012-G-SPA-AC	1	C127	403 022 7703	CERAMIC 33P J 50V	1
or	405 021 0204	TR 2SD1012-F-SPA-AC	1	C128	403 022 7703	CERAMIC 33P J 50V	1
Q108	405 018 2600	TR 2SC3400	1	C129	403 074 2701	CERAMIC 0.047U Z 50V	1
Q109	405 004 4502	TR 2SA608-F-NP-AA	1	C130	403 074 2701	CERAMIC 0.047U Z 50V	1
Q110	405 007 6701	TR 2SB598-F-NP	1	C131	403 038 7209	ELECT 220U M 6.3V	1
or	405 007 6909	TR 2SB598-G-NP	1	C132	403 040 4807	ELECT 220U M 10V	1
Q111	405 021 0600	TR 2SD1012-G-SPA-AC	1	C133	403 040 4807	ELECT 220U M 10V	1
or	405 021 0204	TR 2SD1012-F-SPA-AC	1	C134	403 020 8108	CERAMIC 3P C 50V	1
Q112	405 027 0505	TR 2SK246-GR	1	C135	403 020 8108	CERAMIC 3P C 50V	1
or	405 034 5104	TR 2SK246-BL	1	C136	403 038 2303	ELECT 100U M 6.3V	1
Q113	405 035 8104	TR UN421-D	1	C137	403 067 7409	MT-COMPO 0.039U J 50V	1
Q114	405 035 8005	TR UN411-D	1	C138	403 067 7409	MT-COMPO 0.039U J 50V	1
Q115	405 004 4502	TR 2SA608-F-NP-AA	1	C139	403 049 1708	ELECT 1U M 50V	1
Q117	405 019 2708	TR 2SC536-F-NP	1	C140	403 049 1708	ELECT 1U M 50V	1
or	405 019 3804	TR 2SC536-G-NP	1	C145	403 031 0306	CERAMIC 68P K 50V	1
Q118	405 019 2708	TR 2SC536-F-NP	1	C146	403 031 0306	CERAMIC 68P K 50V	1
or	405 019 3804	TR 2SC536-G-NP	1	C147	403 039 2906	ELECT 47U M 6.3V	1
Q301	405 019 2708	TR 2SC536-F-NP-AA	1	C148	403 038 7209	ELECT 220U M 6.3V	1
or	405 019 3804	TR 2SC536-G-NP-AA	1	C149	403 067 6709	MT-COMPO 0.22U J 50V	1
Q302	405 018 2600	TR 2SC3400	1	C150	403 026 9406	CERAMIC 5P C 50V	1
D101	407 000 3503	VARACTOR DI SVC211SP	1	C151	403 018 8509	CERAMIC 220P K 50V	1
D102	407 007 9904	DIODE GMA01-BT	1	C152	403 050 1209	ELECT 2.2U M 50V	1
D103	407 007 9904	DIODE GMA01-BT	1	C153	403 050 1209	ELECT 2.2U M 50V	1
D104	407 005 3805	DIODE DS442-BT	1	C154	403 085 0802	NP-ELECT 47U M 6.3V	1
D105	407 007 9904	DIODE GMA01-BT	1	C155	403 067 6709	MT-COMPO 0.22U J 50V	1
D106	407 007 9904	DIODE GMA01-BT	1	C156	403 086 1907	NP-ELECT 0.47U M 50V	1
D107	407 007 9904	DIODE GMA01-BT	1	C157	403 073 7004	CERAMIC 470P K 50V	1
D108	407 007 9904	DIODE GMA01-BT	1	C158	403 067 8406	MT-COMPO 0.082U J 50V	1
D109	407 005 3805	DIODE DS442-BT	1	C159	403 073 7004	CERAMIC 470P K 50V	1
D110	407 007 9904	DIODE GMA01-BT	1	C160	403 067 5603	MT-COMPO 0.1U J 50V	1
D111	407 005 3805	DIODE DS442-BT	1	C161	403 074 2701	CERAMIC 0.047U Z 50V	1
D112	407 007 9904	DIODE GMA01-BT	1	C162	403 057 0908	POLYESTER 0.01U K 50V	1
D113	407 007 9904	DIODE GMA01-BT	1	C163	403 067 7805	MT-COMPO 0.47U J 50V	1
D114	407 007 9904	DIODE GMA01-BT	1	C164	403 050 1209	ELECT 2.2U M 50V	1
D115	407 007 9904	DIODE GMA01-BT	1	C165	403 038 2402	ELECT 100U M 6.3V	1
D116	407 007 9904	DIODE GMA01-BT	1	C166	403 074 2701	CERAMIC 0.047U Z 50V	1
D117	407 007 9904	DIODE GMA01-BT	1	C168	403 074 2701	CERAMIC 0.047U Z 50V	1
D118	407 007 9904	DIODE GMA01-BT	1	C169	403 069 8404	CERAMIC 0.01U Z 50V	1
D123	407 005 8602	DIODE ERA15-02	1	C171	403 067 6204	MT-COMPO 0.15U J 50V	1
D124	407 005 8602	DIODE ERA15-02	1	C172	403 059 4102	POLYESTER 2200P K 50V	1
D125	407 005 8602	DIODE ERA15-02	1	C173	403 057 8003	POLYESTER 0.012U K 50V	1
D126	407 005 8602	DIODE ERA15-02	1	C174	403 057 8003	POLYESTER 0.012U K 50V	1
D127	407 005 3805	DIODE DS442	1	C175	403 002 3602	CERAMIC 0.1U K 25V	1
D301	407 007 9904	DIODE GMA01-BT	1	C176	403 002 3602	CERAMIC 0.1U K 25V	1
D302	407 005 3805	DIODE DS442-BT	1	C177	403 067 7805	MT-COMPO 0.47U J 50V	1
D303	407 007 9904	DIODE GMA01-BT	1	C178	403 057 0908	POLYESTER 0.01U K 50V	1
D304	407 007 9904	DIODE GMA01-BT	1	C179	403 067 5603	MT-COMPO 0.1U J 50V	1
D305	407 007 9904	DIODE GMA01-BT	1	C182	403 039 2906	ELECT 47U M 6.3V	1
D307	407 007 9904	DIODE GMA01-BT	1	C183	403 002 3602	CERAMIC 0.1U K 25V	1
D308	407 007 9904	DIODE GMA01-BT	1	C184	403 043 1100	ELECT 220U M 16V	1
D309	407 050 6806	ZENER DIODE GZA7.5X	1	C185	403 050 1209	ELECT 2.2U M 50V	1
D310	407 007 9904	DIODE GMA01-BT	1	C186	403 050 9007	ELECT 33U M 50V	1
D311	407 005 3805	DIODE DS442-BT	1	C187	403 040 4807	ELECT 220U M 10V	1
C101	403 069 8404	CERAMIC 0.01U Z 50V	1	C189	403 040 4807	ELECT 220U M 10V	1
C102	403 038 2303	ELECT 100U M 6.3V	1	C193	403 104 9205	ELECT 220U M 10V	1
C103	403 038 2303	ELECT 100U M 6.3V	1	C194	403 040 4807	ELECT 220U M 10V	1
C104	403 038 2303	ELECT 100U M 6.3V	1	C195	403 039 2906	ELECT 47U M 6.3V	1
C105	403 014 6202	CERAMIC 18P K 50V	1	C196	403 074 2701	CERAMIC 0.047U Z 50V	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
C197	403 074 2701	CERAMIC 0.047U Z 50V	1	R155	401 024 7400	CARBON 10K JA 1/6W	1
C198	403 074 2701	CERAMIC 0.047U Z 50V	1	R156	401 024 7400	CARBON 10K JA 1/6W	1
C200	403 074 2701	CERAMIC 0.047U Z 50V	1	R157	401 027 5502	CARBON 6.8K JA 1/6W	1
C201	404 012 4900	ELECT 3300U M 25V	1	R158	401 027 5502	CARBON 6.8K JA 1/6W	1
C202	404 012 4900	ELECT 3300U M 25V	1	R167	401 027 3003	CARBON 56K JA 1/6W	1
C203	403 072 2703	CERAMIC 0.022U Z 50V	1	R168	401 027 3003	CARBON 56K JA 1/6W	1
C204	403 072 2703	CERAMIC 0.022U Z 50V	1	R169	401 024 7004	CARBON 1K JA 1/6W	1
C207	403 052 8008	ELECT 100U M 35V	1	R170	401 024 7004	CARBON 1K JA 1/6W	1
C208	403 074 2701	CERAMIC 0.047U Z 50V	1	R173	401 027 5502	CARBON 6.8K JA 1/6W	1
C209	403 069 1207	CERAMIC 1000P K 50V	1	R174	401 027 5502	CARBON 6.8K JA 1/6W	1
C210	403 050 7706	ELECT 3.3U M 50V	1	R175	401 025 5405	CARBON 2.2 JA 1/6W	1
C211	403 074 2701	CERAMIC 0.047U Z 50V	1	R176	401 025 5405	CARBON 2.2 JA 1/6W	1
C212	403 074 2701	CERAMIC 0.047U Z 50V	1	R177	401 026 4902	CARBON 330K JA 1/6W	1
C301	403 051 2007	ELECT 4.7U M 50V	1	R178	401 026 1307	CARBON 27K JA 1/6W	1
C302	403 045 0507	ELECT 100U M 25V	1	R179	401 025 5405	CARBON 2.2 JA 1/6W	1
C303	403 045 0507	ELECT 100U M 25V	1	R180	401 025 5405	CARBON 2.2 JA 1/6W	1
C304	403 049 1708	ELECT 1U M 50V	1	R181	401 026 1604	CARBON 270K JA 1/6W	1
C305	403 072 5407	CERAMIC 2700P K 50V	1	R182	401 027 0309	CARBON 47K JA 1/6W	1
C306	403 038 2303	ELECT 100U M 6.3V	1	R183	401 025 8208	CARBON 22K JA 1/6W	1
C307	403 073 7004	CERAMIC 470P K 50V	1	R184	401 024 9305	CARBON 1.2K JA 1/6W	1
C312	403 072 2703	CERAMIC 0.022U Z 50V	1	R185	401 024 7707	CARBON 100K JA 1/6W	1
C313	403 040 4807	ELECT 220U M 10V	1	R186	401 025 8208	CARBON 22K JA 1/6W	1
C314	403 074 2701	CERAMIC 0.047U Z 50V	1	R187	401 027 2600	CARBON 5.6K JA 1/6W	1
C315	403 033 7303	CERAMIC 82P K 50V	1	R188	401 026 1604	CARBON 270K JA 1/6W	1
C316	403 041 3304	ELECT 47U M 10V	1	R189	401 024 7707	CARBON 100K JA 1/6W	1
R101	401 024 7004	CARBON 1K JA 1/6W	1	R190	401 016 4806	CARBON 22K JA 1/4W	1
R102	401 025 2305	CARBON 150K JA 1/6W	1	R191	401 013 7305	CARBON 120K JA 1/4W	1
R103	401 024 7707	CARBON 100K JA 1/6W	1	R192	401 026 4605	CARBON 33K JA 1/6W	1
R104	401 027 2600	CARBON 5.6K JA 1/6W	1	R193	401 024 6700	CARBON 100 JA 1/6W	1
R105	401 026 4605	CARBON 33K JA 1/6W	1	R194	401 025 4606	CARBON 18K JA 1/6W	1
R106	401 027 0507	CARBON 470K JA 1/6W	1	R195	401 025 8208	CARBON 22K JA 1/6W	1
R107	401 024 7707	CARBON 100K JA 1/6W	1	R197	401 025 7805	CARBON 2.2K JA 1/6W	1
R108	401 025 1902	CARBON 15K JA 1/6W	1	R198	401 025 7805	CARBON 2.2K JA 1/6W	1
R109	401 027 2303	CARBON 560 JA 1/6W	1	R199	401 024 7400	CARBON 10K JA 1/6W	1
R110	401 025 7805	CARBON 2.2K JA 1/6W	1	R200	401 024 7400	CARBON 10K JA 1/6W	1
R111	401 026 9600	CARBON 470 JA 1/6W	1	R201	401 027 5502	CARBON 6.8K JA 1/6W	1
R112	401 026 9907	CARBON 4.7K JA 1/6W	1	R202	401 026 8108	CARBON 4.7 JA 1/6W	1
R113	401 024 7707	CARBON 100K JA 1/6W	1	R203	401 025 5405	CARBON 2.2 JA 1/6W	1
R114	401 025 7805	CARBON 2.2K JA 1/6W	1	R204	401 026 4902	CARBON 330K JA 1/6W	1
R115	401 025 8703	CARBON 220K JA 1/6W	1	R205	401 027 9005	CARBON 82K JA 1/6W	1
R116	401 026 0607	CARBON 270 JA 1/6W	1	R206	401 026 8108	CARBON 4.7 JA 1/6W	1
R117	401 026 7408	CARBON 39K JA 1/6W	1	R209	401 026 7606	CARBON 390K JA 1/6W	1
R118	401 024 9701	CARBON 12K JA 1/6W	1	R210	401 025 2305	CARBON 150K JA 1/6W	1
R119	401 026 7408	CARBON 39K JA 1/6W	1	R211	401 026 9907	CARBON 4.7K JA 1/6W	1
R120	401 024 9701	CARBON 12K JA 1/6W	1	R212	401 024 7400	CARBON 10K JA 1/6W	1
R121	401 026 1307	CARBON 27K JA 1/6W	1	R213	401 027 5908	CARBON 68K JA 1/6W	1
R122	401 024 7707	CARBON 100K JA 1/6W	1	R214	401 026 9907	CARBON 4.7K JA 1/6W	1
R123	401 026 4308	CARBON 3.3K JA 1/6W	1	R215	401 026 4902	CARBON 330K JA 1/6W	1
R124	401 026 9907	CARBON 4.7K JA 1/6W	1	R216	401 026 7606	CARBON 390K JA 1/6W	1
R125	401 025 7409	CARBON 220 JA 1/6W	1	R217	401 027 3201	CARBON 560K JA 1/6W	1
R126	401 025 8208	CARBON 22K JA 1/6W	1	R218	401 027 3201	CARBON 560K JA 1/6W	1
R127	401 025 1902	CARBON 15K JA 1/6W	1	R219	401 024 7707	CARBON 100K JA 1/6W	1
R128	401 012 5708	CARBON 1K JA 1/4W	1	R220	401 024 7707	CARBON 100K JA 1/6W	1
R129	401 025 7805	CARBON 2.2K JA 1/6W	1	R221	401 012 8105	CARBON 100K JA 1/4W	1
R130	401 025 8208	CARBON 22K JA 1/6W	1	R222	401 026 8108	CARBON 4.7 JA 1/6W	1
R131	401 025 8208	CARBON 22K JA 1/6W	1	R223	401 025 5405	CARBON 2.2 JA 1/6W	1
R132	401 012 8105	CARBON 100K JA 1/4W	1	R224	401 024 7707	CARBON 100K JA 1/6W	1
R133	401 012 8105	CARBON 100K JA 1/4W	1	R225	401 024 7707	CARBON 100K JA 1/6W	1
R134	401 012 7009	CARBON 10K JA 1/4W	1	R226	401 024 7707	CARBON 100K JA 1/6W	1
R135	401 016 3809	CARBON 2.2K JA 1/4W	1	R227	401 028 0308	CARBON 91K JA 1/6W	1
R136	401 012 7009	CARBON 10K JA 1/4W	1	R228	401 027 3201	CARBON 560K JA 1/6W	1
R137	401 027 0309	CARBON 47K JA 1/6W	1	R229	401 027 5502	CARBON 6.8K JA 1/6W	1
R138	401 012 4503	CARBON 100 JA 1/4W	1	R230	401 027 8602	CARBON 8.2K JA 1/6W	1
R139	401 026 3707	CARBON 33 JA 1/6W	1	R231	401 025 8703	CARBON 220K JA 1/6W	1
R140	401 024 7400	CARBON 10K JA 1/6W	1	R232	401 027 0309	CARBON 47K JA 1/6W	1
R141	401 024 7707	CARBON 100K JA 1/6W	1	R233	401 025 8208	CARBON 22K JA 1/6W	1
R142	401 024 7400	CARBON 10K JA 1/6W	1	R234	401 025 8208	CARBON 22K JA 1/6W	1
R143	401 025 8208	CARBON 22K JA 1/6W	1	R235	401 026 6104	CARBON 36K JA 1/6W	1
R144	401 024 7400	CARBON 10K JA 1/6W	1	R236	401 026 9600	CARBON 470 JA 1/6W	1
R145	401 027 5205	CARBON 680 JA 1/6W	1	R237	401 025 0004	CARBON 120K JA 1/6W	1
R146	401 024 7400	CARBON 10K JA 1/6W	1	R238	401 024 7707	CARBON 100K JA 1/6W	1
R147	401 024 7400	CARBON 10K JA 1/6W	1	R244	401 024 7400	CARBON 10K JA 1/6W	1
R148	401 025 1902	CARBON 15K JA 1/6W	1	R245	401 027 2303	CARBON 560 JA 1/6W	1
R149	401 024 9305	CARBON 1.2K JA 1/6W	1	R246	401 024 7400	CARBON 10K JA 1/6W	1
R150	401 024 9305	CARBON 1.2K JA 1/6W	1	R247	401 024 7400	CARBON 10K JA 1/6W	1
R151	401 025 8703	CARBON 220K JA 1/6W	1	R248	401 012 7009	CARBON 10K JA 1/4W	1
R152	401 025 8703	CARBON 220K JA 1/6W	1	R249	401 025 7805	CARBON 2.2K JA 1/6W	1
R153	401 026 6609	CARBON 390 JA 1/6W	1	R250	401 024 7400	CARBON 10K JA 1/6W	1
R154	401 026 6609	CARBON 390 JA 1/6W	1	R251	401 024 7400	CARBON 10K JA 1/6W	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
R252	401 024 7400	CARBON 10K JA 1/6W	1	VR304	620 190 9630	Potentiometer 200B	1
R253	401 025 7805	CARBON 2.2K JA 1/6W	1	or	620 006 1988	Potentiometer 200B	1
R254	401 012 4909	CARBON 100 JA 1/4W	1	VR305	620 190 9630	Potentiometer 200B	1
R255	401 025 8208	CARBON 22K JA 1/6W	1	or	620 006 1988	Potentiometer 200B	1
R256	401 024 7004	CARBON 1K JA 1/6W	1	VR306	620 190 9630	Potentiometer 200B	1
R257	401 026 4902	CARBON 330K JA 1/6W	1	or	620 006 1988	Potentiometer 200B	1
R258	401 027 0309	CARBON 47K JA 1/6W	1	VR307	620 190 9609	Potentiometer 100KB	1
R259	401 024 7004	CARBON 1K JA 1/6W	1	or	620 006 1933	Potentiometer 100KB	1
R260	402 015 9205	FUSIBLE RES 47 J-1/4W	1	VR308	620 190 9609	Potentiometer 100KB	1
R261	401 024 7707	CARBON 100K JA 1/6W	1	or	620 006 1933	Potentiometer 100KB	1
R262	401 016 1102	CARBON 22 JA 1/4W	1	X301	620 007 3424	FARCL4A-08000	1
R264	402 016 4506	FUSIBLE RES 10 J-1/2W	1	or	620 195 9857	Resonator,Ceramic	1
R265	402 016 4506	FUSIBLE RES 10 J-1/2W	1	IC301	408 016 7704	IC LA3160	1
R266	402 016 4506	FUSIBLE RES 10 J-1/2W	1	IC302	408 016 7704	IC LA3160	1
R267	402 016 4506	FUSIBLE RES 10 J-1/2W	1	IC303	408 020 8704	IC LC4066B	1
R269	401 025 7805	CARBON 2.2K JA 1/6W	1	IC304	408 016 5502	IC LA2000	1
R270	401 016 3809	CARBON 2.2K JA 1/4W	1	IC305	408 173 9504	IC HA12136	1
R271	401 025 7409	CARBON 220 JA 1/6W	1	IC306	408 115 8800	IC TA8121AN	1
R272	401 025 8208	CARBON 22K JA 1/6W	1	IC307	408 115 8800	IC TA8121AN	1
R273	401 026 9600	CARBON 470 JA 1/6W	1	IC308	408 178 7000	IC M50747-795SP	1
R274	401 024 7707	CARBON 100K JA 1/6W	1	IC309	408 020 6601	IC LC4001B	1
R275	401 027 9005	CARBON 82K JA 1/6W	1	IC310	408 020 9800	IC LC4091B	1
R283	401 016 5803	CARBON 220K JA 1/4W	1	IC311	408 145 8405	IC UPC1330HA	1
R301	401 012 2905	CARBON 10 JA 1/4W	1	IC312	408 018 4909	IC LA6458S	1
R302	401 016 1102	CARBON 22 JA 1/4W	1	IC313	408 018 4909	IC LA6458S	1
R303	401 012 2905	CARBON 10 JA 1/4W	1	IC314	408 018 4909	IC LA6458S	1
R304	401 024 7400	CARBON 10K JA 1/6W	1	IC315	408 018 4909	IC LA6458S	1
R305	401 024 7707	CARBON 100K JA 1/6W	1	IC316	408 109 5303	IC LC7823	1
R306	401 024 7004	CARBON 1K JA 1/6W	1	IC317	408 109 5303	IC LC7823	1
R307	401 024 7004	CARBON 1K JA 1/6W	1	Q301	405 019 2807	TR 2SC536-F-SPA-AC	1
R308	401 020 2904	CARBON 47K JA 1/4W	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
R309	401 020 2003	CARBON 4.7K JA 1/4W	1	Q302	405 019 2807	TR 2SC536-F-SPA-AC	1
R310	401 024 7004	CARBON 1K JA 1/6W	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
ASSY,PCB,DECK FUNCTION							
54	620 196 3212	Assy,PCB,Deck Function	1	Q303	405 021 0204	TR 2SD1012-F-SPA-AC	1
	620 017 1977	Pin Jack 4P	2	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
	620 192 4732	Plate Shield	1	Q304	405 021 0204	TR 2SD1012-F-SPA-AC	1
CA803	620 191 6973	Connector 3P Assy	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
CA804	620 191 6959	Connector 2P Assy	1	Q306	405 021 0204	TR 2SD1012-F-SPA-AC	1
CA953	620 191 6942	Connector 5P Assy	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
CN301	620 021 5923	Plug 3P	1	Q307	405 019 2807	TR 2SC536-F-SPA-AC	1
CN302	620 021 3950	Plug 6P	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
CN303	620 021 1970	Plug 2P	1	Q308	405 003 7702	TR 2SA1346	1
CN304	620 021 5596	Plug 8P	1	Q309	405 018 2600	TR 2SC3400	1
CN305	620 021 6555	Plug 4P	1	Q310	405 019 2807	TR 2SC536-F-SPA-AC	1
CN306	620 021 5596	Plug 8P	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
CN307	620 021 6586	Plug 7P	1	Q311	405 018 2600	TR 2SC3400	1
CN308	620 021 2106	Plug 8P	1	Q314	405 018 2600	TR 2SC3400	1
CN309	620 021 7163	Plug 3P	1	Q315	405 018 2600	TR 2SC3400	1
CN310	620 021 9198	Plug 3P	1	Q317	405 018 2600	TR 2SC3400	1
CN311	620 021 6234	Plug 7P	1	Q318	405 018 2600	TR 2SC3400	1
CN312	620 022 0835	Plug 6P	1	Q319	405 018 2600	TR 2SC3400	1
CN313	620 021 5923	Plug 3P	1	Q320	405 018 2600	TR 2SC3400	1
CN314	620 021 8399	Plug 7P	1	Q321	405 018 2600	TR 2SC3400	1
CN315	620 021 9976	Plug 9P	1	Q322	405 018 2600	TR 2SC3400	1
CN316	620 021 8344	Plug 10P	1	Q323	405 019 2807	TR 2SC536-F-SPA-AC	1
CN317	620 021 8313	Plug 3P	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
CN318	620 021 8597	Plug 4P	1	Q324	405 019 2807	TR 2SC536-F-SPA-AC	1
CN319	620 021 7613	Plug 2P	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
CN320	620 021 7613	Plug 2P	1	Q327	405 019 2807	TR 2SC536-F-SPA-AC	1
RA500	620 004 5438	Resistor 8X10K J	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
T301	620 026 4631	Bias Trap 105 Shield	1	Q328	405 019 2807	TR 2SC536-F-SPA-AC	1
T302	620 026 4631	Bias Trap 105 Shield	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
T303	620 026 4440	Bias Trap	1	Q329	405 019 2807	TR 2SC536-F-SPA-AC	1
T304	620 026 4440	Bias Trap	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
T305	620 191 6638	Filter Dolby	1	Q330	405 019 2807	TR 2SC536-F-SPA-AC	1
or	620 029 5864	Filter Dolby	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
T306	620 191 6638	Filter Dolby	1	Q333	405 021 0204	TR 2SD1012-F-SPA-AC	1
or	620 029 5864	Filter Dolby	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
T307	620 027 1899	Coil,6.8MHz/2.2MHz.	1	Q334	405 021 0204	TR 2SD1012-F-SPA-AC	1
T308	620 027 1899	Coil,6.8MHz/2.2MHz.	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
T309	620 028 8668	Coil OSC	1	Q335	405 021 0204	TR 2SD1012-F-SPA-AC	1
VR301	620 190 9630	Potentiometer 200B	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
or	620 006 1988	Potentiometer 200B	1	Q336	405 021 0204	TR 2SD1012-F-SPA-AC	1
VR302	620 190 9630	Potentiometer 200B	1	or	405 021 0600	TR 2SD1012-G-SPA-AC	1
or	620 006 1988	Potentiometer 200B	1	Q337	405 019 2807	TR 2SC536-F-SPA-AC	1
VR303	620 190 9630	Potentiometer 200B	1	or	405 019 3903	TR 2SC536-G-SPA-AC	1
or	620 006 1988	Potentiometer 200B	1	Q338	405 019 2807	TR 2SC536-F-SPA-AC	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
or	405 019 3903	TR 2SC536-G-SPA-AC	1	D328	407 005 3805	DIODE DS442-BT	1
Q339	405 018 2600	TR 2SC3400	1	D329	407 008 0405	DIODE GMB01-BT	1
Q340	405 018 2600	TR 2SC3400	1	C301	403 071 6207	CERAMIC 220P K 50V	1
Q341	405 018 2600	TR 2SC3400	1	C302	403 071 6207	CERAMIC 220P K 50V	1
Q342	405 018 2600	TR 2SC3400	1	C303	403 049 5508	ELECT 10U M 50V	1
Q343	405 018 2600	TR 2SC3400	1	C304	403 049 5508	ELECT 10U M 50V	1
Q344	405 018 2600	TR 2SC3400	1	C305	403 039 7901	ELECT 100U M 10V	1
Q345	405 018 2600	TR 2SC3400	1	C306	403 039 7901	ELECT 100U M 10V	1
Q346	405 018 2600	TR 2SC3400	1	C307	403 072 8200	CERAMIC 330P K 50V	1
Q347	405 003 7702	TR 2SA1346	1	C308	403 072 8200	CERAMIC 330P K 50V	1
Q348	405 018 2600	TR 2SC3400	1	C309	403 059 6601	POLYESTER 0.022U K 50V	1
Q349	405 003 7702	TR 2SA1346	1	C310	403 059 6601	POLYESTER 0.022U K 50V	1
Q350	405 018 2600	TR 2SC3400	1	C311	403 042 3600	ELECT 100U M 16V	1
Q351	405 003 7702	TR 2SA1346	1	C312	403 042 3600	ELECT 100U M 16V	1
Q352	405 018 2600	TR 2SC3400	1	C313	403 050 3708	ELECT 22U M 50V	1
Q353	405 003 7702	TR 2SA1346	1	C314	403 050 3708	ELECT 22U M 50V	1
Q354	405 018 2600	TR 2SC3400	1	C315	403 063 0503	POLYESTER 6800P K 50V	1
Q355	405 003 7702	TR 2SA1346	1	C316	403 063 0503	POLYESTER 6800P K 50V	1
Q356	405 018 2600	TR 2SC3400	1	C317	403 057 8003	POLYESTER 0.012U K 50V	1
Q357	405 019 2807	TR 2SC536-F-SPA-AC	1	C318	403 057 8003	POLYESTER 0.012U K 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C319	403 049 5508	ELECT 10U M 50V	1
Q358	405 019 2807	TR 2SC536-F-SPA-AC	1	C320	403 049 5508	ELECT 10U M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C321	403 074 9205	CERAMIC 680P K 50V	1
Q359	405 024 9907	TR 2SD734-F	1	C322	403 074 9205	CERAMIC 680P K 50V	1
Q360	405 018 2600	TR 2SC3400	1	C323	403 049 5508	ELECT 10U M 50V	1
Q361	405 006 6702	TR 2SA984-F	1	C324	403 049 5508	ELECT 10U M 50V	1
or	405 006 6504	TR 2SA984-E	1	C325	403 039 7901	ELECT 100U M 10V	1
Q362	405 018 2600	TR 2SC3400	1	C326	403 039 7901	ELECT 100U M 10V	1
Q363	405 006 6702	TR 2SA984-F	1	C327	403 048 7701	ELECT 0.47U M 50V	1
or	405 006 6504	TR 2SA984-E	1	C328	403 044 3004	ELECT 470U M 16V	1
Q364	405 018 2600	TR 2SC3400	1	C329	403 059 6601	POLYESTER 0.022U K 50V	1
Q365	405 006 6702	TR 2SA984-F	1	C330	403 059 6601	POLYESTER 0.022U K 50V	1
or	405 006 6504	TR 2SA984-E	1	C331	403 057 8003	POLYESTER 0.012U K 50V	1
Q366	405 013 7006	TR 2SC2274-F	1	C332	403 057 8003	POLYESTER 0.012U K 50V	1
or	405 013 6801	TR 2SC2274-E	1	C333	403 049 5508	ELECT 10U M 50V	1
Q367	405 018 2600	TR 2SC3400	1	C334	403 049 5508	ELECT 10U M 50V	1
Q368	405 008 6700	TR 2SB808-F	1	C335	403 074 6303	CERAMIC 560P K 50V	1
Q369	405 018 2600	TR 2SC3400	1	C336	403 001 2309	CERAMIC 0.01U N 16V	1
Q370	405 008 6700	TR 2SB808-F	1	C337	403 050 3708	ELECT 22U M 50V	1
Q371	405 004 4601	TR 2SA608-F-SPA-AC	1	C338	403 050 3708	ELECT 22U M 50V	1
or	405 004 5103	TR 2SA608-G-SPA-AC	1	C339	403 048 7701	ELECT 0.47U M 50V	1
Q372	405 019 2807	TR 2SC536-F-SPA-AC	1	C340	403 048 7701	ELECT 0.47U M 50V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C341	403 044 0300	ELECT 47U M 16V	1
Q373	405 019 2807	TR 2SC536-F-SPA-AC	1	C342	403 042 3600	ELECT 100U M 16V	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1	C343	403 044 0300	ELECT 47U M 16V	1
Q374	405 003 7702	TR 2SA1346	1	C344	403 049 5508	ELECT 10U M 50V	1
Q375	405 018 2600	TR 2SC3400	1	C345	403 050 1308	ELECT 2.2U M 50V	1
Q376	405 003 7702	TR 2SA1346	1	C346	403 050 1308	ELECT 2.2U M 50V	1
Q377	405 018 2600	TR 2SC3400	1	C347	403 049 5508	ELECT 10U M 50V	1
Q378	405 018 2600	TR 2SC3400	1	C348	403 049 5508	ELECT 10U M 50V	1
Q379	405 018 2600	TR 2SC3400-AC	1	C349	403 074 9205	CERAMIC 680P K 50V	1
D301	407 008 0405	DIODE GMB01-BT	1	C350	403 074 9205	CERAMIC 680P K 50V	1
D302	407 005 3805	DIODE DS442-BT	1	C351	403 081 4705	POLYPRO 2700P J 100V	1
D303	407 008 0405	DIODE GMB01-BT	1	C352	403 081 4705	POLYPRO 2700P J 100V	1
D304	407 008 0405	DIODE GMB01-BT	1	C353	403 049 1708	ELECT 1U M 50V	1
D306	407 005 3805	DIODE DS442-BT	1	C354	403 049 1708	ELECT 1U M 50V	1
D307	407 005 3805	DIODE DS442-BT	1	C355	403 044 3004	ELECT 470U M 16V	1
D308	407 096 5504	DIODE RL1N4003-E	1	C356	403 049 5508	ELECT 10U M 50V	1
or	407 004 9105	DIODE DSF10C-BT	1	C357	403 051 2106	ELECT 4.7U M 50V	1
D309	407 096 5504	DIODE RL1N4003-E	1	C358	403 051 2106	ELECT 4.7U M 50V	1
or	407 004 9105	DIODE DSF10C-BT	1	C359	403 051 2106	ELECT 4.7U M 50V	1
D310	407 005 3805	DIODE DS442-BT	1	C360	403 051 2106	ELECT 4.7U M 50V	1
D311	407 005 3805	DIODE DS442-BT	1	C361	403 051 2106	ELECT 4.7U M 50V	1
D312	407 005 3805	DIODE DS442-BT	1	C362	403 051 2106	ELECT 4.7U M 50V	1
D313	407 005 3805	DIODE DS442-BT	1	C363	403 058 1607	POLYESTER 1500P K 50V	1
D314	407 005 3805	DIODE DS442-BT	1	C364	403 058 1607	POLYESTER 1500P K 50V	1
D315	407 005 3805	DIODE DS442-BT	1	C365	403 050 1308	ELECT 2.2U M 50V	1
D316	407 005 3805	DIODE DS442-BT	1	C366	403 050 1308	ELECT 2.2U M 50V	1
D317	407 005 3805	DIODE DS442-BT	1	C367	403 067 6709	MT-COMPO 0.22U J 50V	1
D318	407 005 3805	DIODE DS442-BT	1	C368	403 067 6709	MT-COMPO 0.22U J 50V	1
D319	407 008 0405	DIODE GMB01-BT	1	C369	403 047 9706	ELECT 0.1U M 50V	1
D320	407 008 0405	DIODE GMB01-BT	1	C370	403 047 9706	ELECT 0.1U M 50V	1
D321	407 008 0405	DIODE GMB01-BT	1	C371	403 048 7701	ELECT 0.47U M 50V	1
D322	407 008 0405	DIODE GMB01-BT	1	C372	403 048 7701	ELECT 0.47U M 50V	1
D323	407 008 0405	DIODE GMB01-BT	1	C373	403 042 0302	ELECT 10U M 16V	1
D324	407 008 0405	DIODE GMB01-BT	1	C374	403 042 0302	ELECT 10U M 16V	1
D325	407 008 0405	DIODE GMB01-BT	1	C375	403 049 1708	ELECT 1U M 50V	1
D326	407 008 0405	DIODE GMB01-BT	1	C376	403 049 1708	ELECT 1U M 50V	1
D327	407 050 5403	ZENER DIODE GZA5.6X	1	C377	403 059 0401	POLYESTER 0.018U K 50V	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty		
C378	403 059 0401	POLYESTER	0.018U K 50V	1	C473	403 045 0606	ELECT	100U M 25V	1
C379	403 058 3700	POLYESTER	0.015U K 50V	1	C474	403 045 0606	ELECT	100U M 25V	1
C380	403 058 3700	POLYESTER	0.015U K 50V	1	C475	403 067 7904	MT-COMPO	0.056U J 50V	1
C381	403 060 2807	POLYESTER	0.027U K 50V	1	C476	403 067 7904	MT-COMPO	0.056U J 50V	1
C382	403 060 2807	POLYESTER	0.027U K 50V	1	C479	403 070 4105	CERAMIC	120P K 50V	1
C383	403 061 4404	POLYESTER	0.039U K 50V	1	C480	403 070 4105	CERAMIC	120P K 50V	1
C384	403 061 4404	POLYESTER	0.039U K 50V	1	C481	403 050 3708	ELECT	22U M 50V	1
C385	403 073 7004	CERAMIC	470P K 50V	1	C482	403 050 3708	ELECT	22U M 50V	1
C386	403 073 7004	CERAMIC	470P K 50V	1	C483	403 067 7409	MT-COMPO	0.039U J 50V	1
C387	403 042 3600	ELECT	100U M 16V	1	C484	403 067 7409	MT-COMPO	0.039U J 50V	1
C388	403 050 1308	ELECT	2.2U M 50V	1	C485	403 033 9406	CERAMIC	820P K 50V	1
C389	403 050 1308	ELECT	2.2U M 50V	1	R301	401 025 8703	CARBON	220K JA 1/6W	1
C390	403 050 1308	ELECT	2.2U M 50V	1	R302	401 025 8703	CARBON	220K JA 1/6W	1
C391	403 045 0606	ELECT	100U M 25V	1	R303	401 024 8001	CARBON	1M JA 1/6W	1
C393	403 001 2309	CERAMIC	0.01U N 16V	1	R304	401 024 8001	CARBON	1M JA 1/6W	1
C394	403 039 7901	ELECT	100U M 10V	1	R305	401 026 9600	CARBON	470 JA 1/6W	1
C395	403 046 4603	ELECT	33U M 25V	1	R306	401 026 9600	CARBON	470 JA 1/6W	1
C396	403 057 0908	POLYESTER	0.01U K 50V	1	R307	401 027 2105	CARBON	56 JA 1/6W	1
C397	403 042 3600	ELECT	100U M 16V	1	R308	401 027 2105	CARBON	56 JA 1/6W	1
C398	403 083 2105	POLYPRO	0.01U J 250V	1	R309	401 025 8208	CARBON	22K JA 1/6W	1
C399	403 071 6207	CERAMIC	220P K 50V	1	R310	401 025 8208	CARBON	22K JA 1/6W	1
C400	403 071 6207	CERAMIC	220P K 50V	1	R311	401 024 7400	CARBON	10K JA 1/6W	1
C401	403 038 2402	ELECT	100U M 6.3V	1	R312	401 013 5301	CARBON	1.2K JA 1/4W	1
C402	403 001 2309	CERAMIC	0.01U N 16V	1	R313	401 027 2600	CARBON	5.6K JA 1/6W	1
C403	403 048 7701	ELECT	0.47U M 50V	1	R314	401 027 2600	CARBON	5.6K JA 1/6W	1
C404	403 051 2106	ELECT	4.7U M 50V	1	R315	401 025 0004	CARBON	120K JA 1/6W	1
C405	403 069 1207	CERAMIC	1000P K 50V	1	R316	401 025 0004	CARBON	120K JA 1/6W	1
C406	403 042 3600	ELECT	100U M 16V	1	R317	401 016 4806	CARBON	22K JA 1/4W	1
C407	403 051 2106	ELECT	4.7U M 50V	1	R318	401 025 8208	CARBON	22K JA 1/6W	1
C408	403 039 7901	ELECT	100U M 10V	1	R319	401 026 9907	CARBON	4.7K JA 1/6W	1
C409	403 067 8208	MT-COMPO	0.068U J 50V	1	R320	401 026 9907	CARBON	4.7K JA 1/6W	1
C410	403 038 2402	ELECT	100U M 6.3V	1	R321	401 025 1902	CARBON	15K JA 1/6W	1
C411	403 042 3600	ELECT	100U M 16V	1	R322	401 014 5201	CARBON	15K JA 1/4W	1
C412	403 051 2106	ELECT	4.7U M 50V	1	R323	401 026 4605	CARBON	33K JA 1/6W	1
C413	403 039 7901	ELECT	100U M 10V	1	R324	401 024 7004	CARBON	1K JA 1/6W	1
C414	403 067 8208	MT-COMPO	0.068U J 50V	1	R325	401 014 5201	CARBON	15K JA 1/4W	1
C415	403 001 2309	CERAMIC	0.01U N 16V	1	R326	401 025 1902	CARBON	15K JA 1/6W	1
C416	403 042 3600	ELECT	100U M 16V	1	R327	401 026 7002	CARBON	3.9K JA 1/6W	1
C417	403 057 0908	POLYESTER	0.01U K 50V	1	R328	401 026 7002	CARBON	3.9K JA 1/6W	1
C418	403 050 1308	ELECT	2.2U M 50V	1	R329	401 024 8001	CARBON	1M JA 1/6W	1
C419	403 042 3600	ELECT	100U M 16V	1	R330	401 024 8001	CARBON	1M JA 1/6W	1
C420	403 044 3004	ELECT	470U M 16V	1	R331	401 027 2600	CARBON	5.6K JA 1/6W	1
C431	403 071 6207	CERAMIC	220P K 50V	1	R332	401 027 2600	CARBON	5.6K JA 1/6W	1
C432	403 071 6207	CERAMIC	220P K 50V	1	R333	401 024 8001	CARBON	1M JA 1/6W	1
C433	403 051 2106	ELECT	4.7U M 50V	1	R334	401 024 8001	CARBON	1M JA 1/6W	1
C434	403 051 2106	ELECT	4.7U M 50V	1	R337	401 027 3003	CARBON	56K JA 1/6W	1
C435	403 026 2209	CERAMIC	47P J 50V	1	R338	401 027 3003	CARBON	56K JA 1/6W	1
C436	403 026 2209	CERAMIC	47P J 50V	1	R339	401 027 3003	CARBON	56K JA 1/6W	1
C437	403 044 0300	ELECT	47U M 16V	1	R340	401 016 2604	CARBON	220 JA 1/4W	1
C438	403 044 0300	ELECT	47U M 16V	1	R341	401 027 8602	CARBON	8.2K JA 1/6W	1
C439	403 059 0401	POLYESTER	0.018U K 50V	1	R342	401 027 8602	CARBON	8.2K JA 1/6W	1
C440	403 059 0401	POLYESTER	0.018U K 50V	1	R343	401 027 3003	CARBON	56K JA 1/6W	1
C441	403 061 8709	POLYESTER	4700P K 50V	1	R344	401 027 3003	CARBON	56K JA 1/6W	1
C442	403 061 8709	POLYESTER	4700P K 50V	1	R345	401 027 3003	CARBON	56K JA 1/6W	1
C443	403 049 1708	ELECT	1U M 50V	1	R346	401 027 9005	CARBON	82K JA 1/6W	1
C444	403 049 1708	ELECT	1U M 50V	1	R347	401 024 7400	CARBON	10K JA 1/6W	1
C445	403 047 4305	ELECT	47U M 25V	1	R348	401 027 9005	CARBON	82K JA 1/6W	1
C446	403 047 4305	ELECT	47U M 25V	1	R349	401 024 7400	CARBON	10K JA 1/6W	1
C447	403 047 4305	ELECT	47U M 25V	1	R350	401 025 8208	CARBON	22K JA 1/6W	1
C448	403 047 4305	ELECT	47U M 25V	1	R351	401 025 8703	CARBON	220K JA 1/6W	1
C449	403 051 2106	ELECT	4.7U M 50V	1	R352	401 025 8703	CARBON	220K JA 1/6W	1
C450	403 051 2106	ELECT	4.7U M 50V	1	R353	401 026 9600	CARBON	470 JA 1/6W	1
C451	403 049 5508	ELECT	10U M 50V	1	R354	401 026 9600	CARBON	470 JA 1/6W	1
C452	403 049 5508	ELECT	10U M 50V	1	R355	401 027 2105	CARBON	56 JA 1/6W	1
C453	403 069 5205	CERAMIC	0.01U K 50V	1	R356	401 027 2105	CARBON	56 JA 1/6W	1
C454	403 049 5508	ELECT	10U M 50V	1	R357	401 027 2600	CARBON	5.6K JA 1/6W	1
C455	403 047 9706	ELECT	0.1U M 50V	1	R358	401 027 2600	CARBON	5.6K JA 1/6W	1
C456	403 069 5205	CERAMIC	0.01U K 50V	1	R359	401 025 0004	CARBON	120K JA 1/6W	1
C457	403 049 5508	ELECT	10U M 50V	1	R360	401 025 0004	CARBON	120K JA 1/6W	1
C458	403 069 5205	CERAMIC	0.01U K 50V	1	R361	401 025 8208	CARBON	22K JA 1/6W	1
C459	403 049 5508	ELECT	10U M 50V	1	R362	401 025 8208	CARBON	22K JA 1/6W	1
C460	403 047 9706	ELECT	0.1U M 50V	1	R363	401 026 9907	CARBON	4.7K JA 1/6W	1
C461	403 069 5205	CERAMIC	0.01U K 50V	1	R364	401 026 9907	CARBON	4.7K JA 1/6W	1
C462	403 049 5508	ELECT	10U M 50V	1	R365	401 025 1902	CARBON	15K JA 1/6W	1
C463	403 069 1207	CERAMIC	1000P K 50V	1	R366	401 025 1902	CARBON	15K JA 1/6W	1
C465	403 049 5508	ELECT	10U M 50V	1	R367	401 027 2600	CARBON	5.6K JA 1/6W	1
C466	403 049 5508	ELECT	10U M 50V	1	R368	401 027 2600	CARBON	5.6K JA 1/6W	1
C467	403 051 2106	ELECT	4.7U M 50V	1	R369	401 024 8001	CARBON	1M JA 1/6W	1
C468	403 051 2106	ELECT	4.7U M 50V	1	R370	401 024 8001	CARBON	1M JA 1/6W	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty		
R371	401 027 5502	CARBON	6.8K JA 1/6W	1	R458	401 025 8703	CARBON	220K JA 1/6W	1
R372	401 027 5502	CARBON	6.8K JA 1/6W	1	R459	401 026 0607	CARBON	270 JA 1/6W	1
R373	401 017 1804	CARBON	2.7K JA 1/4W	1	R460	401 026 0607	CARBON	270 JA 1/6W	1
R374	401 019 1901	CARBON	3.9K JA 1/4W	1	R461	401 024 9008	CARBON	120 JA 1/6W	1
R375	401 025 7805	CARBON	2.2K JA 1/6W	1	R462	401 024 9008	CARBON	120 JA 1/6W	1
R376	401 025 2305	CARBON	150K JA 1/6W	1	R463	401 025 1605	CARBON	1.5K JA 1/6W	1
R378	401 026 9600	CARBON	470 JA 1/6W	1	R464	401 025 1605	CARBON	1.5K JA 1/6W	1
R379	401 022 3107	CARBON	6.8K JA 1/4W	1	R465	401 026 7002	CARBON	3.9K JA 1/6W	1
R381	401 025 8208	CARBON	22K JA 1/6W	1	R466	401 026 7002	CARBON	3.9K JA 1/6W	1
R382	401 025 8208	CARBON	22K JA 1/6W	1	R467	401 026 1000	CARBON	2.7K JA 1/6W	1
R383	401 025 4903	CARBON	180K JA 1/6W	1	R468	401 026 1000	CARBON	2.7K JA 1/6W	1
R384	401 025 4903	CARBON	180K JA 1/6W	1	R469	401 025 1605	CARBON	1.5K JA 1/6W	1
R385	401 012 8105	CARBON	100K JA 1/4W	1	R470	401 025 1605	CARBON	1.5K JA 1/6W	1
R386	401 012 8105	CARBON	100K JA 1/4W	1	R471	401 024 7400	CARBON	10K JA 1/6W	1
R387	401 025 0004	CARBON	120K JA 1/6W	1	R472	401 020 0801	CARBON	470 JA 1/4W	1
R388	401 025 0004	CARBON	120K JA 1/6W	1	R473	401 024 7400	CARBON	10K JA 1/6W	1
R389	401 013 4205	CARBON	120 JA 1/4W	1	R474	401 024 7400	CARBON	10K JA 1/6W	1
R390	401 013 4205	CARBON	120 JA 1/4W	1	R475	401 024 7707	CARBON	100K JA 1/6W	1
R391	401 027 2600	CARBON	5.6K JA 1/6W	1	R476	401 024 7707	CARBON	100K JA 1/6W	1
R392	401 027 2600	CARBON	5.6K JA 1/6W	1	R477	401 021 3009	CARBON	5.6K JA 1/4W	1
R393	401 026 4605	CARBON	33K JA 1/6W	1	R478	401 027 2600	CARBON	5.6K JA 1/6W	1
R394	401 026 4605	CARBON	33K JA 1/6W	1	R479	401 024 9305	CARBON	1.2K JA 1/6W	1
R395	401 026 4308	CARBON	3.3K JA 1/6W	1	R480	401 020 0801	CARBON	470 JA 1/4W	1
R396	401 026 4308	CARBON	3.3K JA 1/6W	1	R481	401 024 7707	CARBON	100K JA 1/6W	1
R399	401 024 7004	CARBON	1K JA 1/6W	1	R482	401 024 7004	CARBON	1K JA 1/6W	1
R400	401 024 7400	CARBON	10K JA 1/6W	1	R483	401 024 7707	CARBON	100K JA 1/6W	1
R401	401 025 8208	CARBON	22K JA 1/6W	1	R484	401 024 7707	CARBON	100K JA 1/6W	1
R402	401 027 8602	CARBON	8.2K JA 1/6W	1	R485	401 024 7707	CARBON	100K JA 1/6W	1
R403	401 027 8602	CARBON	8.2K JA 1/6W	1	R486	401 024 7400	CARBON	10K JA 1/6W	1
R404	401 021 1906	CARBON	560 JA 1/4W	1	R487	401 024 7707	CARBON	100K JA 1/6W	1
R405	401 024 7400	CARBON	10K JA 1/6W	1	R488	401 024 7400	CARBON	10K JA 1/6W	1
R406	401 024 7400	CARBON	10K JA 1/6W	1	R489	401 026 9600	CARBON	470 JA 1/6W	1
R407	401 025 8208	CARBON	22K JA 1/6W	1	R490	401 024 7707	CARBON	100K JA 1/6W	1
R408	401 144 9308	MT-FILM	18K GA 1/6W	1	R491	401 027 9005	CARBON	82K JA 1/6W	1
R409	401 027 0309	CARBON	47K JA 1/6W	1	R492	401 012 7009	CARBON	10K JA 1/4W	1
R410	401 027 0309	CARBON	47K JA 1/6W	1	R493	401 024 7400	CARBON	10K JA 1/6W	1
R411	401 027 5908	CARBON	68K JA 1/6W	1	R494	401 026 9907	CARBON	4.7K JA 1/6W	1
R412	401 027 5908	CARBON	68K JA 1/6W	1	R495	401 024 7400	CARBON	10K JA 1/6W	1
R413	401 026 9907	CARBON	4.7K JA 1/6W	1	R496	401 026 9907	CARBON	4.7K JA 1/6W	1
R414	401 020 2003	CARBON	4.7K JA 1/4W	1	R497	401 024 7400	CARBON	10K JA 1/6W	1
R419	401 027 3003	CARBON	56K JA 1/6W	1	R498	401 026 9907	CARBON	4.7K JA 1/6W	1
R420	401 027 3003	CARBON	56K JA 1/6W	1	R499	401 024 7400	CARBON	10K JA 1/6W	1
R421	401 025 8208	CARBON	22K JA 1/6W	1	R500	401 019 7309	CARBON	430 JA 1/4W	1
R422	401 025 8208	CARBON	22K JA 1/6W	1	R501	401 056 1209	OXIDE-MT	390 JB 1/2W	1
R423	401 026 7408	CARBON	39K JA 1/6W	1	R502	401 055 9107	OXIDE-MT	33 JB 1/2W	1
R424	401 026 7408	CARBON	39K JA 1/6W	1	R503	401 024 7400	CARBON	10K JA 1/6W	1
R425	401 026 7408	CARBON	39K JA 1/6W	1	R504	401 024 7400	CARBON	10K JA 1/6W	1
R426	401 026 7408	CARBON	39K JA 1/6W	1	R505	401 024 6403	CARBON	10 JA 1/6W	1
R427	401 025 8703	CARBON	220K JA 1/6W	1	R506	401 025 7102	CARBON	22 JA 1/6W	1
R428	401 025 8703	CARBON	220K JA 1/6W	1	R507	401 026 9907	CARBON	4.7K JA 1/6W	1
R429	401 025 0004	CARBON	120K JA 1/6W	1	R508	401 024 9008	CARBON	120 JA 1/6W	1
R430	401 025 0004	CARBON	120K JA 1/6W	1	R509	401 026 6609	CARBON	390 JA 1/6W	1
R431	401 024 7400	CARBON	10K JA 1/6W	1	R510	401 012 4503	CARBON	100 JA 1/4W	1
R432	401 024 7400	CARBON	10K JA 1/6W	1	R511	402 015 4309	FUSIBLE RES	33 J- 1/4W	1
R433	401 027 2600	CARBON	5.6K JA 1/6W	1	R512	401 024 7707	CARBON	100K JA 1/6W	1
R434	401 027 2600	CARBON	5.6K JA 1/6W	1	R513	401 027 2105	CARBON	56 JA 1/6W	1
R435	401 026 4308	CARBON	3.3K JA 1/6W	1	R514	401 025 1902	CARBON	15K JA 1/6W	1
R436	401 026 4308	CARBON	3.3K JA 1/6W	1	R515	401 024 7004	CARBON	1K JA 1/6W	1
R437	401 026 9907	CARBON	4.7K JA 1/6W	1	R516	401 026 9600	CARBON	470 JA 1/6W	1
R438	401 026 9907	CARBON	4.7K JA 1/6W	1	R517	401 027 0309	CARBON	4.7K JA 1/6W	1
R439	401 025 8208	CARBON	22K JA 1/6W	1	R518	401 026 9907	CARBON	4.7K JA 1/6W	1
R440	401 025 8208	CARBON	22K JA 1/6W	1	R519	401 024 9008	CARBON	120 JA 1/6W	1
R441	401 027 2600	CARBON	5.6K JA 1/6W	1	R520	401 026 6609	CARBON	390 JA 1/6W	1
R442	401 027 2600	CARBON	5.6K JA 1/6W	1	R521	401 095 1208	MT-FILM	620 JV 1/4W	1
R443	401 027 8602	CARBON	8.2K JA 1/6W	1	R522	401 095 1208	MT-FILM	620 JV 1/4W	1
R444	401 027 8602	CARBON	8.2K JA 1/6W	1	R523	401 012 4503	CARBON	100 JA 1/4W	1
R445	401 024 9701	CARBON	12K JA 1/6W	1	R524	402 015 4309	FUSIBLE RES	33 J- 1/4W	1
R446	401 024 9701	CARBON	12K JA 1/6W	1	R525	401 012 8105	CARBON	100K JA 1/4W	1
R447	401 024 7707	CARBON	100K JA 1/6W	1	R526	401 027 2105	CARBON	56 JA 1/6W	1
R448	401 024 7707	CARBON	100K JA 1/6W	1	R527	401 025 1902	CARBON	15K JA 1/6W	1
R449	401 026 3400	CARBON	300K JA 1/6W	1	R528	401 012 5708	CARBON	1K JA 1/4W	1
R450	401 026 3400	CARBON	300K JA 1/6W	1	R529	401 026 9600	CARBON	470 JA 1/6W	1
R451	401 026 4605	CARBON	33K JA 1/6W	1	R530	401 027 0309	CARBON	4.7K JA 1/6W	1
R452	401 026 4605	CARBON	33K JA 1/6W	1	R531	401 017 0807	CARBON	270 JA 1/4W	1
R453	401 027 6905	CARBON	750 JA 1/6W	1	R532	401 012 7009	CARBON	10K JA 1/4W	1
R454	401 027 6905	CARBON	750 JA 1/6W	1	R533	401 012 7009	CARBON	10K JA 1/4W	1
R455	401 024 9701	CARBON	12K JA 1/6W	1	R534	401 013 5301	CARBON	1.2K JA 1/4W	1
R456	401 024 9701	CARBON	12K JA 1/6W	1	R535	401 025 8208	CARBON	22K JA 1/6W	1
R457	401 025 8703	CARBON	220K JA 1/6W	1	R536	401 024 7400	CARBON	10K JA 1/6W	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
R541	401 024 7004	CARBON 1K JA 1/6W	1	R622	401 024 7004	CARBON 1K JA 1/6W	1
R542	401 024 7004	CARBON 1K JA 1/6W	1	R623	401 024 7707	CARBON 100K JA 1/6W	1
R543	401 024 7707	CARBON 100K JA 1/6W	1	R624	401 024 7707	CARBON 100K JA 1/6W	1
R544	401 024 7707	CARBON 100K JA 1/6W	1	R625	401 024 7707	CARBON 100K JA 1/6W	1
R545	401 024 7707	CARBON 100K JA 1/6W	1	R626	401 024 7707	CARBON 100K JA 1/6W	1
R546	401 024 7707	CARBON 100K JA 1/6W	1	R627	401 026 4605	CARBON 33K JA 1/6W	1
R547	401 026 0607	CARBON 270 JA 1/6W	1	R628	401 026 4605	CARBON 33K JA 1/6W	1
R548	401 026 0607	CARBON 270 JA 1/6W	1	R629	401 012 4503	CARBON 100 JA 1/4W	1
R549	401 025 8703	CARBON 220K JA 1/6W	1	R630	401 024 6700	CARBON 100 JA 1/6W	1
R550	401 025 8703	CARBON 220K JA 1/6W	1	R631	401 026 1307	CARBON 27K JA 1/6W	1
R551	401 025 1902	CARBON 15K JA 1/6W	1	R632	401 026 1307	CARBON 27K JA 1/6W	1
R552	401 025 1902	CARBON 15K JA 1/6W	1	R633	401 027 2600	CARBON 5.6K JA 1/6W	1
R553	401 027 3003	CARBON 56K JA 1/6W	1	R634	401 021 3009	CARBON 5.6K JA 1/4W	1
R554	401 027 3003	CARBON 56K JA 1/6W	1	R635	401 027 8602	CARBON 8.2K JA 1/6W	1
R555	401 012 5708	CARBON 1K JA 1/4W	1	R636	401 023 2802	CARBON 8.2K JA 1/4W	1
R556	401 012 5708	CARBON 1K JA 1/4W	1				
R557	401 026 0607	CARBON 270 JA 1/6W	1				
R558	401 026 0607	CARBON 270 JA 1/6W	1				
R559	401 017 0807	CARBON 270 JA 1/4W	1				
R560	401 017 0807	CARBON 270 JA 1/4W	1				
R561	401 025 8703	CARBON 220K JA 1/6W	1				
R562	401 025 8703	CARBON 220K JA 1/6W	1				
R563	401 024 7707	CARBON 100K JA 1/6W	1				
R564	402 015 4309	FUSIBLE RES 33 J-1/4W	1				
R565	402 015 4309	FUSIBLE RES 33 J-1/4W	1				
R566	402 015 4309	FUSIBLE RES 33 J-1/4W	1				
R567	402 015 4309	FUSIBLE RES 33 J-1/4W	1				
R568	401 024 7707	CARBON 100K JA 1/6W	1				
R569	401 024 7004	CARBON 1K JA 1/6W	1				
R570	401 024 7004	CARBON 1K JA 1/6W	1				
R571	401 026 7408	CARBON 39K JA 1/6W	1				
R572	401 026 7408	CARBON 39K JA 1/6W	1				
R573	401 024 7004	CARBON 1K JA 1/6W	1				
R574	401 024 7004	CARBON 1K JA 1/6W	1				
R575	401 026 7408	CARBON 39K JA 1/6W	1				
R576	401 026 7408	CARBON 39K JA 1/6W	1				
R577	401 024 7400	CARBON 10K JA 1/6W	1				
R578	401 024 7400	CARBON 10K JA 1/6W	1				
R579	401 026 7408	CARBON 39K JA 1/6W	1				
R580	401 026 7408	CARBON 39K JA 1/6W	1				
R581	401 024 7004	CARBON 1K JA 1/6W	1				
R582	401 024 7004	CARBON 1K JA 1/6W	1				
R583	401 026 7408	CARBON 39K JA 1/6W	1				
R584	401 026 7408	CARBON 39K JA 1/6W	1				
R585	401 024 7004	CARBON 1K JA 1/6W	1				
R586	401 024 7004	CARBON 1K JA 1/6W	1				
R587	401 026 7806	CARBON 390K JA 1/6W	1				
R588	401 026 7806	CARBON 390K JA 1/6W	1				
R589	401 026 0607	CARBON 270 JA 1/6W	1				
R590	401 026 0607	CARBON 270 JA 1/6W	1				
R591	401 012 5708	CARBON 1K JA 1/4W	1				
R592	401 024 7004	CARBON 1K JA 1/6W	1				
R593	401 024 7707	CARBON 100K JA 1/6W	1				
R594	401 024 7707	CARBON 100K JA 1/6W	1				
R595	401 024 7707	CARBON 100K JA 1/6W	1				
R596	401 024 7707	CARBON 100K JA 1/6W	1				
R597	401 026 9600	CARBON 470 JA 1/6W	1				
R598	401 026 9600	CARBON 470 JA 1/6W	1				
R599	401 026 9907	CARBON 4.7K JA 1/6W	1				
R600	401 026 9907	CARBON 4.7K JA 1/6W	1				
R603	401 024 6700	CARBON 100 JA 1/6W	1				
R604	401 024 6700	CARBON 100 JA 1/6W	1				
R605	401 026 0607	CARBON 270 JA 1/6W	1				
R606	401 026 0607	CARBON 270 JA 1/6W	1				
R607	401 012 5708	CARBON 1K JA 1/4W	1				
R608	401 024 7004	CARBON 1K JA 1/6W	1				
R609	401 024 7707	CARBON 100K JA 1/6W	1				
R610	401 024 7707	CARBON 100K JA 1/6W	1				
R611	401 027 5908	CARBON 68K JA 1/6W	1				
R612	401 027 5908	CARBON 68K JA 1/6W	1				
R613	401 027 3003	CARBON 56K JA 1/6W	1				
R614	401 027 3003	CARBON 56K JA 1/6W	1				
R615	401 026 1307	CARBON 27K JA 1/6W	1				
R616	401 026 1307	CARBON 27K JA 1/6W	1				
R617	401 026 4605	CARBON 33K JA 1/6W	1				
R618	401 026 4605	CARBON 33K JA 1/6W	1				
R619	401 026 9907	CARBON 4.7K JA 1/6W	1				
R620	401 026 9907	CARBON 4.7K JA 1/6W	1				
R621	401 012 5708	CARBON 1K JA 1/4W	1				

ASSY,PCB,MAIN POWER

55	620 196 5551	Assy,PCB,Main Power	1
	620 017 2721	Fuse Clip	12
	620 022 2587	EC Terminal 1P	2
	620 187 4044	Push Terminal 8P	1
	411 020 8004	SCR S-TPG BRZ 3X8	4
	411 002 8602	SCR PAN 3X6	1
	620 031 4763	Wire Wrap Terminal	6
	620 053 7025	Cover Safety	1
	620 053 9012	Plate Heat Sink	2
	620 053 9036	Plate Heat Sink	1
	620 055 2769	Jumper	1
CA959	620 191 7079	Connector 1P Assy	1
CN951	620 021 5923	Plug 3P	1
CN952	620 021 8344	Plug 10P	1
CN953	620 021 9204	Plug 5P	1
CN954	620 021 8337	Plug 6P	1
CN955	620 021 6548	Plug 2P	1
CN956	620 191 6249	Plug 9P	1
CN957	620 021 7620	Plug 2P	1
CN958	620 021 5947	Plug 5P	1
C967	△ 620 006 6679	Capacitor 0.01MF400V	1
F951	△ 423 006 8700	FUSE 250V T 3.15A	1
F952	△ 423 006 8700	FUSE 250V T 3.15A	1
F953	△ 423 007 2103	FUSE 250V T 4A	1
F954	△ 423 007 2103	FUSE 250V T 4A	1
F956	△ 423 005 7605	FUSE 250V T 1.25A	1
F957	△ 423 005 7605	FUSE 250V T 1.25A	1
L951	620 026 5447	RF Filter	1
L952	620 026 5447	RF Filter	1
RY951	620 017 0406	Relay	1
RY952	620 188 2483	Relay	1
IC951	409 102 0701	IC STK4152MK2-M	1
Q951	405 039 5802	TR 2SC3792	1
Q952	405 039 5802	TR 2SC3792	1
Q953	405 018 2600	TR 2SC3400	1
Q954	405 018 2600	TR 2SC3400	1
Q955	405 019 2807	TR 2SC536-F-SPA-AC	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1
Q956	405 019 2807	TR 2SC536-F-SPA-AC	1
or	405 019 3903	TR 2SC536-G-SPA-AC	1
Q957	405 021 0600	TR 2SD1012-G-SPA-AC	1
or	405 021 0907	TR 2SD1012-H-SPA-AC	1
Q958	405 021 0600	TR 2SD1012-G-SPA-AC	1
or	405 021 0907	TR 2SD1012-H-SPA-AC	1
Q959	405 052 8002	TR 2SB1274-R	1
or	405 052 8101	TR 2SB1274-S	1
Q960	405 073 6407	TR 2SK772-E	1
Q961	405 035 7107	TR 2SD1913-R	1
or	405 035 7206	TR 2SD1913-S	1
Q962	405 073 6407	TR 2SK772-E	1
Q963	405 035 7107	TR 2SD1913-R	1
or	405 035 7206	TR 2SD1913-S	1
Q964	405 035 7107	TR 2SD1913-R	1
or	405 035 7206	TR 2SD1913-S	1
Q965	405 073 6506	TR 2SK772-F	1
Q966	405 035 7107	TR 2SD1913-R	1
or	405 035 7206	TR 2SD1913-S	1
Q967	405 008 4904	TR 2SB764-F	1
or	405 008 4805	TR 2SB764-E	1
D951	407 050 5502	ZENER DIODE GZA5.6Y-BT	1
D952	407 049 6305	ZENER DIODE GZA12Y-BT	1
D953	407 049 7005	ZENER DIODE GZA15Y-BT	1

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
IC802	409 017 0803	IC LA3400	1	C814	403 049 5508	ELECT	10U M 50V
IC804	409 074 0808	IC LA5867	1	C815	403 074 2701	CERAMIC	0.047U Z 50V
IC805	410 065 1605	IC TMP47C870N-4634Z	1	C816	403 074 2701	CERAMIC	0.047U Z 50V
IC806	409 066 7600	IC LM7001	1	C817	403 069 8404	CERAMIC	0.01U Z 50V
Q801	405 027 0505	TR 2SK246-GR	1	C818	403 049 5508	ELECT	10U M 50V
Q807	405 004 4502	TR 2SA608-F-NP-AA	1	C819	403 069 8404	CERAMIC	0.01U Z 50V
or	405 004 5004	TR 2SA608-G-NP	1	C820	403 049 1708	ELECT	1U M 50V
Q808	405 019 2708	TR 2SC536-F-NP-AA	1	C821	403 038 2402	ELECT	100U M 6.3V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C822	403 074 5801	CERAMIC	560P K 50V
Q809	405 004 4502	TR 2SA608-F-NP-AA	1	C824	403 050 7805	ELECT	3.3U M 50V
or	405 004 5004	TR 2SA608-G-NP	1	C825	403 069 8404	CERAMIC	0.01U Z 50V
Q810	405 019 2708	TR 2SC536-F-NP-AA	1	C826	403 049 1708	ELECT	1U M 50V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C827	403 051 2106	ELECT	4.7U M 50V
Q811	405 019 2708	TR 2SC536-F-NP-AA	1	C828	403 026 5408	CERAMIC	47P K 50V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C829	403 051 2106	ELECT	4.7U M 50V
Q812	405 004 4502	TR 2SA608-F-NP-AA	1	C830	403 069 8404	CERAMIC	0.01U Z 50V
or	405 004 5004	TR 2SA608-G-NP	1	C832	403 017 7404	CERAMIC	22P J 50V
Q813	405 021 0204	TR 2SD1012-F-SPA-AC	1	C833	403 088 4104	STYRENE	430P J 50V
or	405 021 0600	TR 2SD1012-G-SPA-AC	1	C838	403 049 5508	ELECT	10U M 50V
Q814	405 021 0204	TR 2SD1012-F-SPA-AC	1	C839	403 057 0908	POLYESTER	0.01U K 50V
or	405 021 0600	TR 2SD1012-G-SPA-AC	1	C840	403 061 4404	POLYESTER	0.039U K 50V
Q815	405 085 5900	TR 2SK246-Y1	1	C841	403 044 0300	ELECT	47U M 16V
or	405 085 5801	TR 2SK246-Y2	1	C842	403 061 8709	POLYESTER	4700P K 50V
Q816	405 016 9502	TR 2SC3069	1	C843	403 072 7906	CERAMIC	330P K 50V
Q818	405 004 4502	TR 2SA608-F-NP-AA	1	C844	403 063 0503	POLYESTER	6800P K 50V
or	405 004 5004	TR 2SA608-G-NP	1	C845	403 056 8608	POLYESTER	1000P K 50V
Q819	405 016 0905	TR 2SC2839-E-SPA-AC	1	C846	403 062 0900	POLYESTER	0.047U K 50V
Q820	405 019 2708	TR 2SC536-F-NP-AA	1	C847	403 049 5508	ELECT	10U M 50V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C848	403 069 8404	CERAMIC	0.01U Z 50V
Q821	405 019 2708	TR 2SC536-F-NP-AA	1	C849	403 050 1308	ELECT	2.2U M 50V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C850	403 044 0300	ELECT	47U M 16V
Q822	405 004 4502	TR 2SA608-F-NP-AA	1	C851	403 072 4509	CERAMIC	270P K 50V
or	405 004 5004	TR 2SA608-G-NP	1	C852	403 072 4509	CERAMIC	270P K 50V
Q823	405 019 2708	TR 2SC536-F-NP-AA	1	C853	403 050 7805	ELECT	3.3U M 50V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C854	403 050 7805	ELECT	3.3U M 50V
Q824	405 017 9501	TR 2SC3330-S-AC	1	C855	403 061 2608	POLYESTER	3900P K 50V
or	405 017 9600	TR 2SC3330-T-AC	1	C856	403 061 2608	POLYESTER	3900P K 50V
Q825	405 017 9501	TR 2SC3330-S-AC	1	C857	403 048 7701	ELECT	0.47U M 50V
or	405 017 9600	TR 2SC3330-T-AC	1	C858	403 049 1708	ELECT	1U M 50V
Q826	405 007 5308	TR 2SB850-F-MP	1	C859	403 022 5907	CERAMIC	33P J 50V
Q827	405 008 6809	TR 2SB808-F-SPA-AC	1	C860	403 022 5907	CERAMIC	33P J 50V
or	405 008 7103	TR 2SB808-G-SPA-AC	1	C861	403 069 8404	CERAMIC	0.01U Z 50V
Q828	405 018 2600	TR 2SC3400-AC	1	C862	403 049 5508	ELECT	10U M 50V
Q829	405 008 6809	TR 2SB808-F-SPA-AC	1	C863	403 069 8404	CERAMIC	0.01U Z 50V
or	405 008 7103	TR 2SB808-G-SPA-AC	1	C864	403 057 0908	POLYESTER	0.01U K 50V
Q830	405 019 2708	TR 2SC536-F-NP-AA	1	C865	403 044 0300	ELECT	47U M 16V
or	405 019 3804	TR 2SC536-G-NP-AA	1	C866	403 069 0705	CERAMIC	1000P K 50V
D801	407 000 4708	VARACTOR DI SVC321C-2	1	C867	403 049 1708	ELECT	1U M 50V
or	407 000 4807	VARACTOR DI SVC321D-2	1	C868	403 044 0300	ELECT	47U M 16V
D802	407 000 4708	VARACTOR DI SVC321C-2	1	C869	403 069 8404	CERAMIC	0.01U Z 50V
or	407 000 4807	VARACTOR DI SVC321D-2	1	C870	403 051 2106	ELECT	4.7U M 50V
D805	407 008 0405	DIODE GMB01-BT	1	C871	403 069 8404	CERAMIC	0.01U Z 50V
D806	407 012 8503	DIODE 1S553	1	C873	404 012 7000	CERAMIC	0.01U P 500V
D807	407 096 5504	DIODE RL1N4003-E	1	C874	403 053 4405	ELECT	2200U M 35V
or	407 004 9105	DIODE DSF10C-BT	1	C875	404 012 7000	CERAMIC	0.01U P 500V
D808	407 096 5504	DIODE RL1N4003-E	1	C876	403 136 1604	ELECT	47U M 100V
or	407 004 9105	DIODE DSF10C-BT	1	C877	403 054 1304	ELECT	47U M 35V
D809	407 050 0408	ZENER DIODE GZA27Y-BT	1	C878	403 054 1304	ELECT	47U M 35V
D810	407 050 6103	ZENER DIODE GZA6.2X-BT	1	C879	403 044 0300	ELECT	47U M 16V
D811	407 012 8503	DIODE 1S553	1	C880	403 049 5508	ELECT	10U M 50V
D812	407 005 3805	DIODE DS442-BT	1	C881	403 050 3708	ELECT	22U M 50V
D814	407 005 3805	DIODE DS442-BT	1	C882	403 049 1708	ELECT	1U M 50V
D815	407 005 3805	DIODE DS442-BT	1	C883	403 026 5408	CERAMIC	47P K 50V
D816	407 005 3805	DIODE DS442-BT	1	C884	403 026 5408	CERAMIC	47P K 50V
D817	407 005 3805	DIODE DS442-BT	1	C885	403 069 0705	CERAMIC	1000P K 50V
D818	407 005 3805	DIODE DS442-BT	1	C886	403 017 7404	CERAMIC	22P J 50V
D819	407 005 3805	DIODE DS442-BT	1	C887	403 038 2402	ELECT	100U M 6.3V
D820	407 005 3805	DIODE DS442-BT	1	C888	403 069 8404	CERAMIC	0.01U Z 50V
D821	407 005 3805	DIODE DS442-BT	1	C889	403 039 1909	ELECT	3300U M 6.3V
D832	407 008 0405	DIODE GMB01-BT	1	C890	403 069 8404	CERAMIC	0.01U Z 50V
D833	407 008 0405	DIODE GMB01-BT	1	C891	403 069 1504	CERAMIC	1000P K 50V
C801	403 074 2701	CERAMIC	0.047U Z 50V	C892	403 069 1504	CERAMIC	1000P K 50V
C802	403 023 1700	CERAMIC	33P K 50V	C893	403 074 2701	CERAMIC	0.047U Z 50V
C804	403 074 2701	CERAMIC	0.047U Z 50V	C894	403 074 2701	CERAMIC	0.047U Z 50V
C806	403 069 8404	CERAMIC	0.01U Z 50V	C896	403 044 0300	ELECT	47U M 16V
C807	403 074 2701	CERAMIC	0.047U Z 50V	C897	403 026 5408	CERAMIC	47P K 50V
C808	403 026 5408	CERAMIC	47P K 50V	R801	401 009 6602	CARBON	3.3K JA 1/2W
C809	403 074 2701	CERAMIC	0.047U Z 50V	R804	401 024 8001	CARBON	1M JA 1/6W
C812	403 074 2701	CERAMIC	0.047U Z 50V	R805	401 024 7004	CARBON	1K JA 1/6W

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
R806	401 024 8001	CARBON	1M JA 1/6W	R910	401 024 7707	CARBON	100K JA 1/6W
R807	401 026 6609	CARBON	390 JA 1/6W	R911	401 027 5502	CARBON	6.8K JA 1/6W
R808	401 026 1000	CARBON	2.7K JA 1/6W	R912	401 025 8208	CARBON	22K JA 1/6W
R809	401 024 7004	CARBON	1K JA 1/6W	R913	401 024 7707	CARBON	100K JA 1/6W
R814	401 027 5502	CARBON	6.8K JA 1/6W	R914	401 027 9005	CARBON	82K JA 1/6W
R815	401 026 1000	CARBON	2.7K JA 1/6W	R915	401 026 9600	CARBON	47K JA 1/6W
R817	401 016 4806	CARBON	22K JA 1/4W	R916	401 025 8208	CARBON	22K JA 1/6W
R818	401 027 5502	CARBON	6.8K JA 1/6W	R917	401 024 7400	CARBON	10K JA 1/6W
R819	401 027 0309	CARBON	47K JA 1/6W	R918	401 024 7400	CARBON	10K JA 1/6W
R820	401 024 7707	CARBON	100K JA 1/6W	R919	401 024 7400	CARBON	10K JA 1/6W
R821	401 024 7400	CARBON	10K JA 1/6W	R920	401 012 7009	CARBON	10K JA 1/4W
R822	401 024 7707	CARBON	100K JA 1/6W	R921	401 024 7400	CARBON	10K JA 1/6W
R824	401 018 3807	CARBON	3.3K JA 1/4W	R922	401 024 7400	CARBON	10K JA 1/6W
R825	401 027 0309	CARBON	47K JA 1/6W	R925	401 024 7400	CARBON	10K JA 1/6W
R826	401 012 8105	CARBON	100K JA 1/4W	R926	401 012 7009	CARBON	10K JA 1/4W
R827	401 025 8208	CARBON	22K JA 1/6W	R927	401 012 7009	CARBON	10K JA 1/4W
R828	401 020 2003	CARBON	4.7K JA 1/4W	R928	401 012 7009	CARBON	10K JA 1/4W
R829	401 014 4105	CARBON	1.5K JA 1/4W	R929	401 024 7400	CARBON	10K JA 1/6W
R830	401 020 2904	CARBON	47K JA 1/4W	R930	401 027 5502	CARBON	6.8K JA 1/6W
R831	401 025 4606	CARBON	18K JA 1/6W	R931	401 026 9907	CARBON	4.7K JA 1/6W
R832	401 024 6700	CARBON	100 JA 1/6W	R932	401 012 4503	CARBON	100 JA 1/4W
R833	401 024 7707	CARBON	100K JA 1/6W	R933	401 026 4308	CARBON	3.3K JA 1/6W
R834	401 027 0309	CARBON	47K JA 1/6W	R934	401 024 7400	CARBON	10K JA 1/6W
R835	401 012 4107	CARBON	100 JA 1/4W	R935	401 024 7400	CARBON	10K JA 1/6W
R836	401 016 1102	CARBON	22 JA 1/4W	R936	401 024 7400	CARBON	10K JA 1/6W
R837	401 024 7004	CARBON	1K JA 1/6W	R937	401 024 7400	CARBON	10K JA 1/6W
R839	401 012 4503	CARBON	100 JA 1/4W	R938	401 024 7400	CARBON	10K JA 1/6W
R840	401 026 9907	CARBON	4.7K JA 1/6W	R939	401 024 7400	CARBON	10K JA 1/6W
R849	401 012 8105	CARBON	100K JA 1/4W	R940	401 024 7400	CARBON	10K JA 1/6W
R850	401 016 1102	CARBON	22 JA 1/4W	R941	401 024 7400	CARBON	10K JA 1/6W
R851	401 025 4903	CARBON	180K JA 1/6W	R942	401 024 7400	CARBON	10K JA 1/6W
R852	401 025 4903	CARBON	180K JA 1/6W	R943	401 024 7400	CARBON	10K JA 1/6W
R853	401 026 4308	CARBON	3.3K JA 1/6W	R944	401 024 7400	CARBON	10K JA 1/6W
R854	401 026 4308	CARBON	3.3K JA 1/6W	R945	401 024 7400	CARBON	10K JA 1/6W
R855	401 018 3807	CARBON	3.3K JA 1/4W	R946	401 026 9907	CARBON	4.7K JA 1/6W
R856	401 026 4308	CARBON	3.3K JA 1/6W	R947	401 024 7707	CARBON	100K JA 1/6W
R859	401 027 2800	CARBON	5.6K JA 1/6W	R948	401 026 9907	CARBON	4.7K JA 1/6W
R860	401 027 2800	CARBON	5.6K JA 1/6W	R949	401 012 8105	CARBON	100K JA 1/4W
R861	401 025 8703	CARBON	220K JA 1/6W				
R862	401 025 8703	CARBON	220K JA 1/6W				
R863	401 026 1000	CARBON	2.7K JA 1/6W				
R864	401 025 7805	CARBON	2.2K JA 1/6W				
R866	401 027 0309	CARBON	47K JA 1/6W				
R867	401 024 7400	CARBON	10K JA 1/6W				
R868	401 024 7707	CARBON	100K JA 1/6W				
R869	401 027 0309	CARBON	47K JA 1/6W				
R870	401 027 0309	CARBON	47K JA 1/6W				
R872	401 026 4308	CARBON	3.3K JA 1/6W				

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
	620 051 9731	Spacer LED	5	VOLUME P.C.B. ASSY			
	620 121 2549	Spacer Lamp	1	62	620 190 7230	Volume P.C.B. Assy	1
CA315	620 191 6867	Connector 9P Assy	1	CA951	620 191 6880	Connector 3P Assy	1
CA316	620 191 6874	Connector 10P Assy	1	CN501	620 021 8337	Plug 6P	1
CA741	620 191 6584	Connector 7P Assy	1	CN502	620 021 7820	Plug 2P	1
S781	620 016 7819	Tact Switch 160G	1	CN503	620 021 5923	Plug 3P	1
or	620 195 9628	Switch,Tact	1	VR501	620 190 9647	Motor VR 2X20KA	1
S782	620 016 7819	Tact Switch 160G	1	IC501	409 114 4803	IC LB1641	1
or	620 195 9628	Switch,Tact	1	D501	407 050 5502	ZENER DIODE GZA5.6V	1
S783	620 016 7819	Tact Switch 160G	1	C501	403 067 5603	MT-COMPO 0.01U J 50V	1
or	620 195 9628	Switch,Tact	1	C502	403 057 0908	POLYESTER 0.01U K 50V	1
S784	620 016 7819	Tact Switch 160G	1	C503	403 058 1607	POLYESTER 1500P K 50V	1
or	620 195 9628	Switch,Tact	1	C504	403 058 1607	POLYESTER 1500P K 50V	1
S785	620 016 7819	Tact Switch 160G	1	C505	403 067 7904	MT-COMPO 0.056U J 50V	1
or	620 195 9628	Switch,Tact	1	C506	403 067 7904	MT-COMPO 0.056U J 50V	1
S786	620 016 7819	Tact Switch 160G	1	R641	402 016 4506	FUSIBLE RES 10 J- 1/2W	1
or	620 195 9628	Switch,Tact	1	R642	401 026 7002	CARBON 3.9K JA 1/6W	1
S787	620 016 7819	Tact Switch 160G	1	R643	401 026 7002	CARBON 3.9K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	DOLBY SWITCH P.C.B. ASSY			
S788	620 016 7819	Tact Switch 160G	1	63	620 190 7247	Dolby Switch P.C.B. Assy	1
or	620 195 9628	Switch,Tact	1	CA312	620 191 6836	Connector 6P Assy	1
S789	620 016 7819	Tact Switch 160G	1	CN741	620 022 0231	Plug 7P	1
or	620 195 9628	Switch,Tact	1	S741	620 190 9845	Rotary Switch 2-3	1
S790	620 016 7819	Tact Switch 160G	1	S742	620 190 9852	Rotary Switch 2-2	1
or	620 195 9628	Switch,Tact	1	VR741	620 190 9586	VR 2X50KA	1
Q781	405 018 2600	TR 2SC3400	1	D741	407 008 0405	DIODE GMB01-BT	1
Q782	405 018 2600	TR 2SC3400	1	D742	407 008 0405	DIODE GMB01-BT	1
Q783	405 018 2600	TR 2SC3400	1	D743	407 008 0405	DIODE GMB01-BT	1
Q784	405 018 2600	TR 2SC3400	1	HEADPHONE P.C.B. ASSY			
Q785	405 004 4601	TR 2SA608-F-SPA-AC	1	64	620 190 7254	Headphone P.C.B. Assy	1
or	405 004 5103	TR 2SA608-G-SPA-AC	1		620 190 2242	Jack 7P Black	1
Q786	405 004 4601	TR 2SA608-F-SPA-AC	1	CA958	620 020 8840	Connector 5P Assy	1
or	405 004 5103	TR 2SA608-G-SPA-AC	1	R781	401 060 3008	OXIDE-MT 220 JA 1W	1
Q787	405 004 4601	TR 2SA608-F-SPA-AC	1	R782	401 060 3008	OXIDE-MT 220 JA 1W	1
or	405 004 5103	TR 2SA608-G-SPA-AC	1	R783	401 055 5307	OXIDE-MT 220 JA 1/2W	1
Q789	405 004 4601	TR 2SA608-F-SPA	1	R784	401 055 5307	OXIDE-MT 220 JA 1/2W	1
or	405 004 5103	TR 2SA608-G-SPA	1	T1 SWITCH P.C.B. ASSY			
Q790	405 018 2600	TR 2SC3400	1	65	620 190 7261	T1 Switch P.C.B. Assy	1
D771	407 109 1202	LED SLB-25VR3F	1	CA317	620 191 6881	Connector 3P Assy	1
D772	407 109 1202	LED SLB-25VR3F	1	S751	620 016 7819	Tact Switch 160G	1
D773	407 109 1202	LED SLB-25VR3F	1	or	620 195 9628	Switch,Tact	1
D774	407 109 1202	LED SLB-25VR3F	1	S752	620 016 7819	Tact Switch 160G	1
D775	407 008 0405	DIODE GMB01-BT	1	or	620 195 9628	Switch,Tact	1
D776	407 008 0405	DIODE GMB01-BT	1	D751	407 008 0405	DIODE GMB01-BT	1
D777	407 112 7208	LED SLB-55MG3F	1	D752	407 008 0405	DIODE GMB01-BT	1
D778	407 112 7109	LED SLB-55VR3F	1	T2 SWITCH P.C.B. ASSY			
D779	407 112 7208	LED SLB-55MG3F	1	66	620 190 7278	T2 Switch P.C.B. Assy	1
D780	407 112 7208	LED SLB-55MG3F	1	CA318	620 191 6898	Connector 4P Assy	1
D781	407 112 7208	LED SLB-55MG3F	1	S761	620 016 7819	Tact Switch 160G	1
D782	407 008 0405	DIODE GMB01-BT	1	or	620 195 9628	Switch,Tact	1
D783	407 008 0405	DIODE GMB01-BT	1	S762	620 016 7819	Tact Switch 160G	1
D784	407 005 3605	DIODE D5442-BT	1	or	620 195 9628	Switch,Tact	1
D785	407 008 0405	DIODE GMB01-BT	1	S763	620 016 7819	Tact Switch 160G	1
D786	407 008 0405	DIODE GMB01-BT	1	or	620 195 9628	Switch,Tact	1
D787	407 008 0405	DIODE GMB01-BT	1	S764	620 016 7819	Tact Switch 160G	1
D788	407 008 0405	DIODE GMB01-BT	1	or	620 195 9628	Switch,Tact	1
D789	407 008 0405	DIODE GMB01-BT	1	D761	407 008 0405	DIODE GMB01-BT	1
D790	407 008 0405	DIODE GMB01-BT	1	D762	407 008 0405	DIODE GMB01-BT	1
D791	407 008 0405	DIODE GMB01-BT	1	D763	407 008 0405	DIODE GMB01-BT	1
R781	402 015 6402	FUSIBLE RES 2.2 J- 1/4W	1	D764	407 008 0405	DIODE GMB01-BT	1
R782	401 026 0607	CARBON 270 JA 1/6W	1	VR IND P.C.B. ASSY			
R783	401 026 0607	CARBON 270 JA 1/6W	1	67	620 190 7285	VR IND P.C.B. Assy	1
R784	401 026 0607	CARBON 270 JA 1/6W	1	CA502	620 018 1952	Connector 2P Assy	1
R785	401 026 0607	CARBON 270 JA 1/6W	1	D721	407 113 4503	LED SLP-646B-50	1
R786	401 024 7400	CARBON 10K JA 1/6W	1	PCB CD-CONTROL ASSY			
R787	401 024 7400	CARBON 10K JA 1/6W	1	68	620 190 8008	PCB CD-Control Assy	1
R788	401 024 7400	CARBON 10K JA 1/6W	1		620 182 6654	Digitron 12-BT-24KG	1
R789	401 024 7400	CARBON 10K JA 1/6W	1		620 191 9356	Cushion	1
R790	401 024 7400	CARBON 10K JA 1/6W	1	CN1	620 022 1924	Plug 8P	1
R791	401 025 7409	CARBON 220 JA 1/6W	1	CN2	620 022 1931	Plug 9P	1
R792	401 026 0607	CARBON 270 JA 1/6W	1	CN3	620 022 1931	Plug 9P	1
R793	401 025 7409	CARBON 220 JA 1/6W	1	CN4	620 022 1924	Plug 8P	1
R794	401 025 7409	CARBON 220 JA 1/6W	1	S101	620 016 7819	Tact Switch 160G	1
R795	401 025 7409	CARBON 220 JA 1/6W	1				

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
or	620 195 9628	Switch,Tact	1	PL.POWER P.C.B. ASSY			
S102	620 016 7819	Tact Switch 160G	1	69	620 191 1329	PL.Power P.C.B. Assy	1
or	620 195 9628	Switch,Tact	1		411 020 8004	SCR S-TPG BRZ 3X8	1
S103	620 016 7819	Tact Switch 160G	1		620 053 8084	Plate Heat Sink	1
or	620 195 9628	Switch,Tact	1	Q997	405 035 7107	TR 2SD1913-R	1
S104	620 016 7819	Tact Switch 160G	1	or	405 035 7206	TR 2SD1913-S	1
or	620 195 9628	Switch,Tact	1	D997	407 049 6305	ZENER DIODE GZA12Y-BT	1
S105	620 016 7819	Tact Switch 160G	1	C997	403 049 5508	ELECT 10U M 50V	1
or	620 195 9628	Switch,Tact	1	C998	403 043 4903	ELECT 33U M 16V	1
S106	620 016 7819	Tact Switch 160G	1	C999	403 042 3600	ELECT 100U M 16V	1
or	620 195 9628	Switch,Tact	1	R995	401 061 0105	OXIDE-MT 3.3 JB 1W	1
S107	620 016 7819	Tact Switch 160G	1	R996	401 014 4105	CARBON 1.5K JA 1/4W	1
or	620 195 9628	Switch,Tact	1	NOTES:			
S108	620 016 7819	Tact Switch 160G	1	1. Parts order must contain Model Number, Part Number and Description.			
or	620 195 9628	Switch,Tact	1	2. Ordering quantity of screws and resistors must be multiple of 10 pcs.			
S109	620 016 7819	Tact Switch 160G	1	PRODUCT SAFETY NOTICE			
or	620 195 9628	Switch,Tact	1				
S110	620 016 7819	Tact Switch 160G	1	Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol Δ in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified with Δ , use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.			
or	620 195 9628	Switch,Tact	1				
S111	620 016 7819	Tact Switch 160G	1	Q1	405 078 5504	TR DTA124T-S	1
or	620 195 9628	Switch,Tact	1	D1	407 007 9904	DIODE GMA01-BT	1
S112	620 016 7819	Tact Switch 160G	1	D2	407 007 9904	DIODE GMA01-BT	1
or	620 195 9628	Switch,Tact	1	D3	407 007 9904	DIODE GMA01-BT	1
S113	620 016 7819	Tact Switch 160G	1	D4	407 007 9904	DIODE GMA01-BT	1
or	620 195 9628	Switch,Tact	1	D5	407 007 9904	DIODE GMA01-BT	1
S114	620 016 7819	Tact Switch 160G	1	D6	407 007 9904	DIODE GMA01-BT	1
or	620 195 9628	Switch,Tact	1	D7	407 007 9904	DIODE GMA01-BT	1
S115	620 016 7819	Tact Switch 160G	1	D8	407 007 9904	DIODE GMA01-BT	1
or	620 195 9628	Switch,Tact	1	R1	401 025 8208	CARBON 22K JA 1/6W	1
S116	620 016 7819	Tact Switch 160G	1	R2	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	R3	401 025 8208	CARBON 22K JA 1/6W	1
S117	620 016 7819	Tact Switch 160G	1	R4	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	R5	401 025 8208	CARBON 22K JA 1/6W	1
S118	620 016 7819	Tact Switch 160G	1	R6	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	R7	401 025 8208	CARBON 22K JA 1/6W	1
S119	620 016 7819	Tact Switch 160G	1	R8	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	R9	401 025 8208	CARBON 22K JA 1/6W	1
S120	620 016 7819	Tact Switch 160G	1	R10	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1	R11	401 025 8208	CARBON 22K JA 1/6W	1
S121	620 016 7819	Tact Switch 160G	1	R12	401 025 8208	CARBON 22K JA 1/6W	1
or	620 195 9628	Switch,Tact	1				
S122	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S123	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S124	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S125	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S126	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S127	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				
S128	620 016 7819	Tact Switch 160G	1				
or	620 195 9628	Switch,Tact	1				

TK-TC 94HB 4

1 2152 45090 A

S765 REL

S765 PRUSE

S763 REW

S764 FF


CA315

1 2152 45090 A

1 2152 45090 A

- 38 -


TUNER PRINTED CIRCUIT BOARD (BOTTOM VIEW)



IC PIN NUMBERS DC VOLTAGES																					
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC801	LA1266	2.4V	2.3V	2.3V	0V	12.3V	12.3V	12.3V	5.0V	3.4V	2.3V	5.5V	3.1V	0V	1.5V	1.5V	0V	0V	2.4V	1.5V	0V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		3.8V	3.8V	3.8V	2.5V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
IC802	LA3400	3.2V	3.2V	3.2V	3.2V	5.7V	3.2V	3.2V	5.7V	3.2V	0V	0V	0V	5.2V	4.9V	0V	1.7V	3.1V	2.8V	2.9V	2.9V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		3.5V	12.6V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
IC804	LA5667	22.9V	0V	4.9V	22.8V	5.5V	0.1V	13.1V	—	—	—	—	—	—	—	—	—	—	—	—	
IC805	TMP47C870N	-26.8V	-26.6V	-21.5V	-21.5V	-21.5V	-23.7V	-23.7V	-21.3V	-20.7V	-23.7V	-21.3V	-16.5V	-26.2V	0V	1.6V	1.6V	1.6V	0V	2.3V	2.2V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		4.6V	4.9V	5.5V	0V	0V	0V	0V	0V	0.6V	0.6V	0V	5.5V	0V	0V	3.6V	2.1V	0V	0V	0V	0V
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
		5.5V	0V	5.5V	0V	0V	0V	0V	-24.2V	-24.2V	-24.2V	-24.3V	-24.3V	-24.3V	-24.3V	-24.2V	-24.3V	-24.3V	-24.2V	-24.3V	-26.3V
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
		-26.5V	-26.5V	-26.3V	4.7V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
IC806	LM7001	1.5V	1.5V	0V	0V	0V	0V	2.6V	2.3V	13.0V	0V	2.7V	5.4V	5.4V	0.7V	2.3V	0V	—	—	—	


TRANSISTOR DC VOLTAGES																			
Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E
Q807	2SA608	3.3V	3.8V	3.9V	Q818	2SA608	12.5V	0V	12.3V	Q826	2SB560	-27.3V	-55.3V	-26.8V					
Q808	2SC536	0.6V	0V	0V	Q819	2SC2839	1.9V	12.2V	1.2V	Q827	2SB808	13.0V	0V	13.1V					
Q809	2SA608	1.5V	1.5V	1.5V	Q820	2SC536	0V	5.5V	0V	Q828	2SC3400	0V	13.0V	0V					
Q811	2SC536	0.6V	0V	0V	Q821	2SC536	0V	5.5V	0V	Q829	2SB808	5.5V	0V	5.5V					
Q812	2SA608	5.1V	-0.2V	5.5V	Q822	2SA608	4.7V	-0.6V	2.7V	Q830	2SC536	12.7V	13.0V	12.1V					
Q813	2SD1012	-2.7V	0V	0V	Q823	2SC536	-0.4V	4.6V	0V			D	G	S					
Q814	2SD1012	-2.7V	0V	0V	Q824	2SC3330	-24.3V	4.7V	-24.4V	Q801	2SK246	10.6V	4.7V	4.7V					
Q816	2SC3069	0.5V	1.5V	0V	Q825	2SC3330	-24.3V	4.7V	-24.4V	Q815	2SK246	5.1V	0.7V	1.1V					

FRONT CONTROL P.C.BOARD (BOTTOM VIEW)



TRANSISTOR DC VOLTAGES														
Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E
Q651	2SC3400	0V	3.7V	0V	Q658	2SD734	0V	14.5V	0V	Q665	2SA1346	0V	0V	5.1V
Q652	2SC3400	0V	2.5V	0V	Q659	2SD734	0V	0V	0V	Q666	2SC3400	0V	5.0V	0V
Q653	2SC3400	0V	2.5V	0V	Q660	2SD734	0V	14.5V	0V	Q667	2SA608	4.5V	0V	4.9V
Q654	2SC3400	0V	2.5V	0V	Q661	2SD1012	0V	4.9V	0V	Q668	2SC3400	0V	4.4V	0V
Q655	2SC3400	0V	2.5V	0V	Q662	2SD1012	0V	4.9V	0V	Q669	2SC3400	0.6V	0V	0V
Q656	2SC3400	4.9V	0V	0V	Q663	2SC536	-21.8V	5.0V	-21.9V	Q670	2SC536	0.6V	0V	0V
Q657	2SD734	0V	14.5V	0V	Q664	2SC536	-21.8V	5.1V	-21.9V					


GRAPHIC EQUALIZER P.C.BOARD
(BOTTOM VIEW)



Graphic Equalizer P.C.Board Voltage Table

		IC PIN NUMBERS DC VOLTAGES																			
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC761,762	AN7337	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	10.5V	0V	-10.5V
IC765	LA6458D	0V	0V	0V	-10.5V	0V	0V	0V	10.5V	-	-	-	-	-	-	-	-	-	-	-	-

MAIN POWER P.C.BOARD
(BOTTOM VIEW)




(Main Power P.C.Board Voltage Table)

IC PIN NUMBERS DC VOLTAGES																			
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
IC951	STK4152	- 0.1V	- 0.1V	0V	- 32.9V	- 1.2V	0V	0V	0V	- 35.0V	0V	35.1V	33.2V	0V	- 35.0V	- 1.3V	0V	- 0.1V	- 0.1V

TRANSISTOR DC VOLTAGES														
Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E
Q951	2SC3792	0V	0V	0V	Q957	2SD1012	0.6V	0V	0V	Q966	2SD1913	5.6V	0V	5.1V
Q952	2SC3792	0V	0V	0V	Q958	2SD1012	0.6V	0V	0V	Q967	2SB764	- 25.3V	- 31.6V	- 24.6V
Q953	2SC3400	4.9V	0V	0V	Q959	2SB1274	- 17.8V	- 32.9V	0V			D	G	S
Q954	2SC3400	0V	9.8V	0V	Q961	2SD1913	17.8V	0V	17.1V	Q960	2SK772	- 17.8V	- 32.4V	- 32.8V
Q955	2SC536	0.6V	0.5V	0V	Q963	2SD1913	12.2V	24.5V	11.6V	Q962	2SK772	32.8V	17.8V	17.8V
Q956	2SC536	0.6V	0V	0V	Q964	2SD1913	15.1V	24.0V	14.5V	Q965	2SK772	0V	15.1V	15.1V

DECK FUNCTION P.C. BOARD (BOTTOM VIEW)



[illegible][illegible]

Pcd. No.	DEVICE	IC PIN NUMBERS DC VOLTAGES																			
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC102	LC7880N	0V	4.4V	0.8V	2.4V	0V	0.5V	0.5V	0.5V	0.4V	0.5V	0.4V	0V	0.5V	0.5V	0.5V	0.5V	0V	0.5V	0.5V	
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
		0.5V	0.4V	0V	0V	0V	0V	0.4V	0.5V	0.5V	0.5V	0.5V	0.4V	0V	0V	0V	0V	4.9V	4.9V	4.9V	
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	
		4.8V	0.8V	5.0V	0V	4.9V	0V	0V	5.0V	4.9V	4.9V	4.9V	4.9V	4.9V	0.5V	0V	0V	4.9V	4.9V	4.9V	
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	
		0V	3.3V	0.5V	0.5V	5.0V	0V	5.0V	1.0V	0V	0V	0V	4.9V	5.0V	0V	4.9V	0V	0V	0.1V	5.0V	

Pcd. No.	DEVICE	IC PIN NUMBERS DC VOLTAGES																			
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC102	LC7880N	0V	4.4V	0.8V	2.4V	0V	0.5V	0.5V	0.5V	0.4V	0.5V	0.4V	0V	0.5V	0.5V	0.5V	0.5V	0V	0.5V	0.5V	
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
		0.5V	0.4V	0V	0V	0V	0V	0.4V	0.5V	0.5V	0.5V	0.5V	0.4V	0V	0V	0V	0V	4.9V	4.9V	4.9V	
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	
		4.8V	0.8V	5.0V	0V	4.9V	0V	0V	5.0V	4.9V	4.9V	4.9V	4.9V	4.9V	0.5V	0V	0V	4.9V	4.9V	4.9V	
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	
		0V	3.3V	0.5V	0.5V	5.0V	0V	5.0V	1.0V	0V	0V	0V	4.9V	5.0V	0V	4.9V	0V	0V	0.1V	5.0V	

[illegible][illegible][illegible][illegible][illegible][illegible]

Voltage Table of Front Control P.C.Board


Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC651	LC8554	4.9V	4.9V	4.9V	0V	—	—	0V	27	28	29	30	31	32	33	34	35	36	37	38	39
		0V	4.8V	0V	0V	0V	4.9V	0V	0V	0V	0V	2.4V	4.9V	0V	0V	4.9V	0.5V	0.5V	0.5V	0.5V	0.5V
		4.1	4.2	4.3	4.4	4.5	4.6	4.7	4.8	4.9	5.0	5.1	5.2	5.3	5.4	5.5	5.6	5.7	5.8	5.9	6.0
		0.5V	0.5V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
IC652	L78L05	15.1V	6.6V	0V	4.9V	4.9V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
		5.0V	—21.7V	—24.3V	—24.3V	—24.3V	—24.3V	—24.3V	—24.3V	—24.3V	—24.3V	—24.3V	—21.7V	—24.3V	—21.7V	—24.3V	—	—	—	—	—
IC653	654	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
		—21.7V	5.0V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
IC655	656	BA1271	0V	0V	0V	9.4V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
IC657	658	BA1271	0V	0V	0V	9.4V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V

Voltage Table of Deck/Function P.C.Board


Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC301	302	LA3180	1.3V	0.7V	4.2V	9.7V	0V	4.2V	0V	1.3V	—	—	—	—	—	—	—	—	—	—	—
		IC303	7.1V	7.1V	7.1V	7.0V	0V	0V	0V	7.0V	7.0V	7.0V	12.9V	12.9V	14.3V	—	—	—	—	—	—
		IC304	1.9V	0V	1.9V	0V	0V	0V	0.3V	5.9V	5.9V	0.4V	5.9V	0V	1.1V	5.8V	0V	5.8V	—	—	—
		IC305	COA101P	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0.3V	5.1V	0.6V	11.5V	0V	16.4V	0V
IC306	307	TA8121AN	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39
			1.6V	0V	1.5V	5.9V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
			5.6V	0V	0V	0V	5.5V	0V	0V	5.6V	0V	5.5V	0V	0V	0V	0V	0V	0V	0V	5.5V	5.6V
			21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39
			5.5V	0V	5.5V	0V	0V	5.5V	0V	5.5V	2.1V	2.4V	0V	5.6V	5.6V	5.6V	5.6V	5.6V	5.6V	5.6V	5.6V
			41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59
			5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V	5.5V
			61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
			0V	0V	0V	0V	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
IC309	LC4001B	5.5V	5.5V	0V	5.6V	0V	0V	0V	0V	0V	0V	5.6V	0V	5.6V	5.5V	5.6V	—	—	—	—	—
			0V	0V	0V	0V	0V	0V	0V	0V	0V	0.1V	0V	0V	0V	4.9V	—	—	—	—	—
IC310	LC4081B	0V	0V	0.1V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
IC311	UPC1330	0V	0V	0V	0V	0V	13.0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
IC312	LA6458S	16.0V	0V	0V	0V	0V	—15.8V	0V	0V	15.9V	—	—	—	—	—	—	—	—	—	—	—
			16.0V	0V	0V	0V	—16.0V	0V	0V	16.0V	—	—	—	—	—	—	—	—	—	—	—
IC313	LA6458S	16.0V	0V	0V	0V	0V	—16.0V	0V	0V	16.0V	—	—	—	—	—	—	—	—	—	—	—
IC314	LA6458S	16.0V	0V	0V	0V	0V	—16.0V	0V	0V	16.0V	—	—	—	—	—	—	—	—	—	—	—
IC315	LA6458S	15.9V	0V	0V	0V	0V	—16.0V	0V	0V	15.9V	—	—	—	—	—	—	—	—	—	—	—
IC316	LC7823	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
			0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
			—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
			21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39
			0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V
IC317	LC7823	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
			0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V

Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E
Q301	2SC536	0.6V	0V	0V	Q328	2SC536	—0.3V	0V	0V	Q355	2SC3400	0V	14.4V	0V
Q302	2SC536	0.6V	0V	0V	Q329	2SC536	—0.3V	0V	0V	Q357	2SC536	0V	5.5V	0V
Q303	2SD1012	0.8V	0V	0V	Q330	2SC536	—0.3V	0V	0V	Q358	2SC536	0.7V	0V	0V
Q304	2SD1012	0.8V	0V	0V	Q333	2SD1012	0.6V	0V	0V	Q359	2SD1012	6.2V	11.5V	5.6V
Q305	2SD1012	0.8V	0V	0V	Q334	2SD1012	0.6V	0V	0V	Q360	2SC3400	0V	14.4V	0V
Q306	2SD1012	0.8V	0V	0V	Q335	2SD1012	0.7V	0V	0V	Q361	2SC3400	14.5V	0V	14.5V
Q307	2SC536	0.6V	0V	0V	Q336	2SD1012	0.7V	0V	0V	Q362	2SC3400	14.4V	0V	0V
Q308	2SA1346	14.4V	0V	14.5V	Q337	2SC536	1.2V	4.7V	0.6V	Q363	2SA1346	0V	0V	0V
Q309	2SC3400	0V	14.4V	0V	Q338	2SC536	1.2V	5.0V	0.6V	Q364	2SC3400	0V	0V	0V
Q310	2SC536	0V	12.9V	0V	Q339	2SC3400	8.3V	0V	0V	Q365	2SA1346	0V	0V	0V
Q311	2SC3400	0V	12.9V	0V	Q340	2SC3400	8.3V	0V	0V	Q366	2SC2724	0V	0V	0V
Q312	2SC536	0V	0V	0V	Q341	2SC3400	0V	0V	0V	Q367	2SC3400	0V	11.6V	0V
Q313	2SC536	0V	0V	0V	Q342	2SC3400	0V	0V	0V	Q368	2SC3400	11.0V	11.5V	11.4V
Q314	2SC3400	0V	0.6V	0V	Q343	2SC3400	0V	0V	0V	Q369	2SC3400	0V	11.4V	0V
Q315	2SC3400	0V	0V	0V	Q344	2SC3400	0V	0V	0V	Q370	2SB698	11.4V	11.5V	11.5V
Q316	2SC3400	0V	0V	0V	Q345	2SC3400	14.4V	0V	0V	Q371	2SA698	4.9V	5.5V	5.5V
Q317	2SC3400	0V	0V	0V	Q346	2SC3400	14.4V	0V	0V	Q372	2SD1012	0V	5.6V	0V
Q318	2SC3400	0V	0V	0V	Q347	2SA1346	14.5V	14.5V	0V	Q373	2SD1012	0V	5.5V	0V
Q319	2SC3400	5.2V	0V	0V	Q348	2SC3400	5.6V	0V	0V	Q374	2SC3400	0V	14.4V	0V
Q320	2SC3400	5.2V	0V	0V	Q349	2SC3400	5.6V	0V	0V	Q375	2SC3400	0V	14.4V	0V
Q321	2SC3400	13.8V	0V	0V	Q350	2SA1346	0V	14.4V	0V	Q376	2SA1346	0V	14.4V	0V
Q322	2SC3400	13.8V	0V	0V	Q351	2SC3400	5.6V	0V	0V	Q377	2SC3400	5.5V	0V	0V
Q323	2SC536	6.4V	12.1V	5.6V	Q352	2SA1346	14.4V	0V	0V	Q378	2SC3400	5.5V	0V	0V
Q324	2SC536	6.4V	5.6V	0V	Q353	2SC3400	0V	14.4V	0V	Q379	2SC3400	0V	8.5V	0V
Q325	2SC536	0V	0V	0V	Q354	2SA1346	14.4V	0V	0V	Q380	2SC3400	0V	0V	0V
Q326	2SC536	0V	0V	0V	Q355	2SA1346	14.4V	0V	0V	Q381	2SC3400	0V	0V	0V
Q327	2SC536	—0.3V	0.2V	0V	Q356	2SA1346	14.4V	0V	14.5V	Q382	2SC3400	0V	0V	0V


SUB TRANS P.C.BOARD (BOTTOM VIEW)




WIRING DIAGRAM (CD Player Section)




WIRING DIAGRAM (Power Main Section)




WIRING DIAGRAM (Main Unit Section)



SCHEMATIC DIAGRAM (Deck/Function/Front Control Section)



SCHEMATIC DIAGRAM (Deck/Function Section)




CD MAIN P.C.B. A

DIGITRON 12-BT-17GK


CD CONTROL P.C.B. ASSY

SCHEMATIC DIAGRAM (Main Power Section)




IC BLOCK DIAGRAM


LA1266 BLOCK DIAGRAM



LA3400 BLOCK DIAGRAM




TMP47C870N-4634Z BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


LM7001 BLOCK DIAGRAM




LA5667 BLOCK DIAGRAM




LA3160 BLOCK DIAGRAM




LC4066B BLOCK DIAGRAM



LA2000 BLOCK DIAGRAM




M50747-795SP BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


HA12136 BLOCK DIAGRAM




TA8121AN BLOCK DIAGRAM




LA6458S BLOCK DIAGRAM




LC7823 BLOCK DIAGRAM




AN7337 BLOCK DIAGRAM



BA14741 BLOCK DIAGRAM




LA5537 BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


LB1641 BLOCK DIAGRAM




LC7880 BLOCK DIAGRAM



TA79L005P BLOCK DIAGRAM




STK4152MK2-M BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


L78LR05E-MA BLOCK DIAGRAM




AN79L07 BLOCK DIAGRAM




LC3517BS-15 BLOCK DIAGRAM




LA6500 BLOCK DIAGRAM




LA6462D BLOCK DIAGRAM




LC7860N BLOCK DIAGRAM



UPC4570HA BLOCK DIAGRAM




LA6510 BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


LA6393S BLOCK DIAGRAM




LC4081B BLOCK DIAGRAM




NJU74HCU04D BLOCK DIAGRAM




LC4001B BLOCK DIAGRAM




UPC1330HA BLOCK DIAGRAM



TA78L007P BLOCK DIAGRAM




NJM7805A BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)

LA9200NM BLOCK DIAGRAM




LC6538D-3843 BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)

LC6554H-3863 BLOCK DIAGRAM



LC7566 BLOCK DIAGRAM




M-CON PORT ASSIGNMENTS (LC651 LC6554H)

Signal Name	I/O	Function	Active H/L	Port Name	Pin No.
MUTE	OUT	Audio Mute Output	L	PN0	1
SP.RELAY	OUT	Speaker Relay Control	H	PN1	2
POWER RLY	OUT	System Power Supply Control	H	PN2	3
DECK CONT.	OUT	Manual Dubbing Control	H	PN3	4
				PO0	5
				PO1	6
DIMMER	OUT	Dimmer Control	H	PO2	7
PEAK HOLD	OUT	Peak Hold Control	H	PO3	8
DISPLAY	OUT	Display Control	H	PP0	9
KEY A	IN	Key Matrix	L	PA0	10
KEY B	IN	Key Matrix	L	PA1	11
KEY C	IN	Key Matrix	L	PA2	12
KEY D	IN	Key Matrix	L	PA3	13
POWER SW	IN	Power ON/OFF Switch	L	PB0	14
REC DET	IN	Record Detect Input	L	PB1	15
PROTECT IN	IN	Protect Detect Input	L	PB2	16
				PB3	17
KEY 1	OUT	Key Matrix Timing	L	PC0	18
KEY 2	OUT	Key Matrix Timing	L	PC1	19
KEY 3	OUT	Key Matrix Timing	L	PC2	20
KEY 4	OUT	Key Matrix Timing	L	PC3	21
REMOCON	IN	Remote Control	L	PD0	22
DI	OUT	Analog Switch Data Output	H	PD1	23
CE	OUT	Analog Switch Chip Enable Output	H	PD2	24
CL	OUT	Analog Switch Clock Output	H	PD3	25
		Connect the PF3		PE0	26
VOLUME DOWN	OUT	Motor Drive Volume (Down)	H	PE1	27
VOLUME UP	OUT	Motor Drive Volume (UP)	H	PE2	28
FCRS CONT	OUT	FCRS Control	H	PE3	29
				TEST	30
				VSS	31
				OSC1	32
				OSC2	33
				RES	34
DATA IN	IN	Data Input	L	PF0	35
DATA OUT	OUT	Data Output	H	PF1	36
				PF2	37
				PF3	38
TAPE1 MODE	IN	TAPE-1 FF/REW Detect	L	PG0	39
TAPE1 MODE	IN	TAPE-1 FF/REW Detect	L	PG1	40
TAPE2 MODE	IN	TAPE-2 FF/REW Detect	L	PG2	41
TAPE2 MODE	IN	TAPE-2 FF/REW Detect	L	PG3	42
				P10	43
				P11	44
				P12	45
				P13	46


IC & TRANSISTOR LEAD IDENTIFICATION

TRANSISTOR	FRONT VIEW	BOTTOM VIEW	TRANSISTOR	FRONT VIEW	BOTTOM VIEW
2SA608 2SA984 2SB598 2SC2274 2SC3069 2SC3792 2SC536 2SD734			2SB560 2SB764		
UN411-D UN421-D			2SB1274 2SD1913		
DTA124T 2SA1346 2SA608 2SB808 2SC2839 2SC2999 2SC3330 2SC3400 2SC536 2SD1012			2SK246		
2SK772					
TERMINAL NAME					
B → BASE S → SOURCE C → COLLECTOR G → GATE E → EMITTER D → DRAIN					


**LA2000 FRONT/SIDE VIEWS
LA6393S FRONT/SIDE VIEWS
LA6458S FRONT/SIDE VIEWS**




UPC1330HA FRONT/SIDE VIEWS




LB1641 FRONT/SIDE VIEWS




LA3160 FRONT/SIDE VIEWS



UPC4570HA FRONT/SIDE VIEWS




LA5537 FRONT/SIDE VIEWS




IC & TRANSISTOR LEAD IDENTIFICATION (Continued)


LA5667 FRONT/SIDE VIEWS




STK4152MK2-M FRONT/SIDE VIEWS




LA6510 FRONT/SIDE VIEWS




LA6462D TOP VIEW




LC4001B TOP VIEW
LC4066B TOP VIEW
LC4081B TOP VIEW
NJU74HCU04D TOP VIEW




BA14741 TOP VIEW




LM7001 TOP VIEW




AN7337 TOP VIEW
LC7880 TOP VIEW




LA3400 TOP VIEW




TA8121AN TOP VIEW




LA1266 TOP VIEW
LC3517BS-15 TOP VIEW




LC7823 TOP VIEW




LC7566 TOP VIEW




M50747-795SP TOP VIEW



LC6538D-3843 TOP VIEW
LC6554H-3863 TOP VIEW




TA78L007P TOP/SIDE VIEWS
TA79L005P TOP/SIDE VIEWS




IC & TRANSISTOR LEAD IDENTIFICATION (Continued)


LA9200NM TOP/SIDE VIEWS




LC7860N TOP/SIDE VIEWS



AN79L07 TOP/SIDE VIEWS



NJM7805A TOP/SIDE VIEWS



LA6500 TOP/SIDE VIEWS

